



Wireless Headphone

ZEB **THUNDER** NEO



## User Manual

[www.zebronics.com](http://www.zebronics.com)

Thank you for purchasing **ZEB-THUNDER NEO (ZEB-WHP12)** Wireless Headphone. Please read this user manual carefully and keep it for future reference.

**Note:**

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the products or it results in the voiding the product's Warranty.
- Turn off the speaker when the speaker is not in use.
- To know more about Terms and conditions for warranty policy, please visit:

<https://zebronics.com/pages/warranty-policy>

**Features:**

BT & AUX Connections

Dual Pairing

Voice Assistant Support

Low Latency Gaming mode

Environmental Noise Cancellation (ENC)

Soft & Comfortable Earcushions

Adjustable Headband

Call Function

Built-in Rechargeable Battery

Type-C Charging

Rapid Charging (10min charge for 7 h\* use)

## **Specifications:**



|                        |                                 |
|------------------------|---------------------------------|
| Model No.              | : ZEB-WHP 12                    |
| BT version             | : 5.4                           |
| Wireless range         | : 10 meters (Without obstacles) |
| Driver Size            | : 40mm                          |
| Speaker Impedance      | : 32Ω                           |
| Frequency Response     | : 20Hz - 20kHz                  |
| Driver Sensitivity     | : 110±3dB                       |
| Charging time          | : 1.5h                          |
| Playback time          | : 60h*                          |
| Talk time              | : 40h*                          |
| Microphone Impedance   | : 1.0kΩ                         |
| Microphone Sensitivity | : -24dB±3dB                     |
| Net. Weight            | : 160g                          |

## **Package Contents :**

|                |      |
|----------------|------|
| Headphone      | : 1U |
| Charging cable | : 1U |
| Aux cable      | : 1U |
| QR code guide  | : 1U |

*\* at 50% volume*

## Product Representation :





## **General Instruction :**

### **Button Controls :**

- Long press "MFB" or Power button" to On/Off
- Single press "+" button: Increase Volume
- Single press "-" button: Decrease Volume
- Single press "MFB or Power button" to Answer/Hang up the phone call
- Long press "+" button for Next Track
- Long press "-" button for Previous Track
- Hold the "Play/Pause" button for 3 sec for 3 EQ Modes (Sound Monster Mode, Vocal Enhance Mode, Equalizer Mode).
- Double press the "MFB" to Switch between Gaming/Music Mode.

### **Bluetooth Mode :**

- The headphone enters BT mode as soon as it is powered ON. (Refer LED indication and make sure aux is not connected already)
- Now search for nearby BT devices in your audio source device.
- Tap on the BT name "ZEB-THUNDER NEO" to pair.

### **Dual Pairing Mode :**

- Pair the headphone with one device and do not unpair, now turn off the BT on the first device and pair the headphone with the second device.

- Now you can turn on the first device and the headphone will automatically pair with the first device (if your device is compatible) else tap on **"ZEB-THUNDER NEO"** in the BT settings on your first device.

### **AUX Mode :**

- Connect one end of the 3.5mm aux cable to the headphone and connect the other end to any compatible audio source device. (Example: Mobile, Tablet, Laptop, Desktop Computer, etc)
- Media controls can be done via the audio source device. (Make sure to power on the headphone to use BT mode after removing the aux cable)

### **Gaming Mode (Low Latency) :**

- Double press the MFB button to enable gaming mode and repeat the process to enter into music mode.

### **LED Indication :**

- Charging- Constant Red LED glows
- Full Charge - Red LED goes OFF
- Bluetooth Discover Mode - Blue and Red LED blinks rapidly
- Bluetooth Connected - Constant Blue LED Blinks.

