



Wireless Headphone

ZEB **THUNDER** NEO



User Manual

www.zebronics.com



Thank you for purchasing **ZEB-THUNDER NEO (ZEB-WHP12)** Wireless Headphone. Please read this user manual carefully and keep it for future reference.

Note:

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the products or it results in the voiding the product's Warranty.
- Turn off the speaker when the speaker is not in use.
- To know more about Terms and conditions for warranty policy, please visit:

<https://zebronics.com/pages/warranty-policy>

Features:

BT & AUX Connections

Dual Pairing

Voice Assistant Support

Low Latency Gaming mode

Environmental Noise Cancellation (ENC)

Soft & Comfortable Earcushions

Adjustable Headband

Call Function

Built-in Rechargeable Battery

Type-C Charging

Rapid Charging (10min charge for 7 h* use)

Specifications:



Model No.	: ZEB-WHP 12
BT version	: 5.4
Wireless range	: 10 meters (Without obstacles)
Driver Size	: 40mm
Speaker Impedance	: 32Ω
Frequency Response	: 20Hz - 20kHz
Driver Sensitivity	: 110±3dB
Charging time	: 1.5h
Playback time	: 60h*
Talk time	: 40h*
Microphone Impedance	: 1.0kΩ
Microphone Sensitivity	: -24dB±3dB
Net. Weight	: 160g

Package Contents :

Headphone	: 1U
Charging cable	: 1U
Aux cable	: 1U
QR code guide	: 1U

** at 50% volume*

Product Representation :



General Instruction :

Button Controls :

- Long press "MFB" or Power button" to On/Off
- Single press "+" button: Increase Volume
- Single press "-" button: Decrease Volume
- Single press "MFB or Power button" to Answer/Hang up the phone call
- Long press "+" button for Next Track
- Long press "-" button for Previous Track
- Hold the "Play/Pause" button for 3 sec for 3 EQ Modes (Sound Monster Mode, Vocal Enhance Mode, Equalizer Mode).
- Double press the "MFB" to Switch between Gaming/Music Mode.

Bluetooth Mode :

- The headphone enters BT mode as soon as it is powered ON. (Refer LED indication and make sure aux is not connected already)
- Now search for nearby BT devices in your audio source device.
- Tap on the BT name "ZEB-THUNDER NEO" to pair.

Dual Pairing Mode :

- Pair the headphone with one device and do not unpair, now turn off the BT on the first device and pair the headphone with the second device.

- Now you can turn on the first device and the headphone will automatically pair with the first device (if your device is compatible) else tap on **"ZEB-THUNDER NEO"** in the BT settings on your first device.

AUX Mode :

- Connect one end of the 3.5mm aux cable to the headphone and connect the other end to any compatible audio source device. (Example: Mobile, Tablet, Laptop, Desktop Computer, etc)
- Media controls can be done via the audio source device. (Make sure to power on the headphone to use BT mode after removing the aux cable)

Gaming Mode (Low Latency) :

- Double press the MFB button to enable gaming mode and repeat the process to enter into music mode.

LED Indication :

- Charging- Constant Red LED glows
- Full Charge - Red LED goes OFF
- Bluetooth Discover Mode - Blue and Red LED blinks rapidly
- Bluetooth Connected - Constant Blue LED Blinks.

