

SHIELD_XENSIV_A XENSIV™ sensor shield release notes

About this document

Scope and purpose

Thank you for your interest in the SHIELD_XENSIV_A XENSIV™ sensor shield. This document lists kit contents, installation requirements, kit documentation, and limitations.



Table of contents

Table of contents

About this document 1
 Table of contents 2
 1 Release contents 3
 1.1 Kit contents 3
 2 Tool information 4
 2.1 Software and tools 4
 2.2 Code examples and kit collateral 4
 2.3 Installation 4
 2.4 Kit revision 4
 2.5 Known issues and limitations 4
 2.6 Documentation 4
 2.7 Technical support 4
 2.8 Additional information 4
 Disclaimer 6

1 Release contents

1 Release contents

1.1 Kit contents

The SHIELD_XENSIV_A XENSIV™ sensor shield includes the following:

- XENSIV™ sensor shield
- Quick start guide

2 Tool information

2 Tool information

2.1 Software and tools

Code examples for this shield require ModusToolbox™ software version 3.1 or later. This is available on the [ModusToolbox™ software](#) webpage. Refer to the kit guide for more details.

2.2 Code examples and kit collateral

The kit [webpage](#) contains both the documents and hardware files. Additionally, the code examples are available in the [Infineon GitHub repository](#).

2.3 Installation

All the required software installation instructions are provided in the kit guide, which is available on the kit [webpage](#).

2.4 Kit revision

This is the initial revision (Rev. **) of the SHIELD_XENSIV_A XENSIV™ sensor shield.

2.5 Known issues and limitations

- **Power consumption limitation**

XENSIV™ sensor shield consumes higher power when both, the PAS CO2 sensor and RADAR sensor (configured in continuous wave mode) are operated simultaneously. This can exceed the base board's power capabilities, leading to issues with sensor operation and system performance

Workaround:

- Consider using the external USB power supply (from **J11** USB connector) option provided on the XENSIV™ sensor shield, if simultaneous operation is required.

2.6 Documentation

The following kit documents are available on the kit [webpage](#).

- SHIELD_XENSIV_A XENSIV™ sensor shield kit guide
- SHIELD_XENSIV_A XENSIV™ sensor shield quick start guide
- SHIELD_XENSIV_A XENSIV™ sensor shield release notes

2.7 Technical support

For assistance or product-related queries, contact [Infineon Support](#) or post your queries on the [Infineon Developer Community](#).

2.8 Additional information

- For more information about the ModusToolbox™ software functionality and releases, see the [ModusToolbox™ software](#) webpage
- For a list of trainings on ModusToolbox™ software, see the [ModusToolbox™ Software Training](#) webpage
- For more information about the XENSIV™ PAS CO2 sensor portfolio and technical documentation, see [CO2 sensors](#)

2 Tool information

- For more information about the XENSIV™ pressure sensor portfolio and technical documentation, see [Pressure sensors for IoT](#)
- For more information about the XENSIV™ 60 GHz RADAR sensor product portfolio and technical documentation, see [XENSIV™ 60 GHz radar MMICs](#)
- For more information about the XENSIV™ MEMS microphone portfolio and technical documentation, see [XENSIV™ MEMS microphones for consumer electronics](#)
- For more information about the OPTIGA™ embedded security solutions and technical documentation, see [OPTIGA™ embedded security solutions](#)

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition 2024-11-04

Published by

Infineon Technologies AG
81726 Munich, Germany

© 2024 Infineon Technologies AG
All Rights Reserved.

Do you have a question about any aspect of this document?

Email: erratum@infineon.com

Document reference
IFX-apb1711611463762

Important notice

The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics ("Beschaffenhheitsgarantie").

With respect to any examples, hints or any typical values stated herein and/or any information regarding the application of the product, Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights of any third party.

In addition, any information given in this document is subject to customer's compliance with its obligations stated in this document and any applicable legal requirements, norms and standards concerning customer's products and any use of the product of Infineon Technologies in customer's applications.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

Warnings

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.