折页线


330.0 mm

CCAQCY-T8 mm 使用前,请先下载安装QCY手机APP客户端 以获得更便捷的耳机操控体验 0.09 功能介绍 使用场景 状 态 耳机不在充电盒内,呈关机状态 轻按触控面板约2秒 开机 耳机在充电盒内(充电盒有电, 开盖,耳机开机(有霍尔开关功能 开机状态下,充电盒有电 关机 耳机在开机状态下 接听电话/结束电话 来电响铃中/通话中 拒接来电 来电响铃中 唤醒语音助手 在连接状态下 音乐暂停/播放 音乐状态下

音乐状态下

切换下一曲

认识耳机



LED

蓝灯闪烁

红灯长亮2秒

- TYPE-C USB充电

更多操作方法请关注二维码

语音提示

TONE音

TONE音

TONE音

TONE音

TONE音

双耳机配对

首次配对方法:

打开充电盒,耳机自动开机,开机后双耳自动组队成功,耳 机进入配对状态,手机搜索连接"QCY-T8"即可完成双耳与 手机的连接。

切换设备配对方法:

QCY蓝牙耳机售后服务

保修期: 自产品购买之日起12个月(请妥善保管购买凭证) 免费服务:

售后服务与支持 保修期;


三包凭证

产品信息:

用户信息:

联系电话

购买信息: 销售单位



的权利。 1。自常购买之日起7日内,本产品出现故障。经由QCY售后服务中心确定为产品 质量问题。可享受钱理、要收、惠货的服务。 2。自常购买之知达15日内,本产品出现故障。经由QCY售后服务中心确定为产 品质量问题。可享令性理或更换的服务。 3。自常购买之日起2个月内。本产品出现故障,经由QCY售后服务中心确定为 产品质量问题。可享受修理的服务。

日 即形式上记在17 门间设在市场下水山。 全用品保修期间,风霜产品本身质量引起的故障。请用户凭购买凭证与经销商取 模型系以享受富压服务。 均有任何产品损害或期益率可归进于产品质量本身,则不在保修范围内。有下列 情形若不属于保修范围内。 1. 因天次、地震、雷达、异耳巴亚、环境因素而发生之故障或毁损的。 2. 自行或是托生级师,提供理论是一商标准、改装或更换非别「零件。 3. 未按使用于册据作或因人为使用不当而追或损坏者。如产品浸水、腐蚀、掉落、 衍生或指在月本温度好成下。

恢复出厂设置

方法一: 清除配对记录 (此方法用于无法正常连接时) 1. 已有连接过手机,在手机蓝牙设备列表中,找到QCY-T8,点击进入设置,选择忽略或取消配对。

点击进入坡置,选择忽略或取消配灯。 2. 取出两只耳机,同时长按触控面板5秒,直至红灯长亮2秒 后熄灭,表示进入关机状态。 3. 关机后再次同时长按双耳触控面板约10秒,直至双耳红蓝 好交替闪3次。表示重置成功,之后双耳会自动开机重新组队。 *恢复出厂后用首次配对的方法连接即可正常使用



FAQ



方法二: 打开充电盒盖子,长按充电盒按键10秒至充电盒指示 灯显示红蓝交替闪3下后,关闭盖子完成重置





佩戴耳机



1.将耳帽斜向下轻轻塞入耳道,以轻摆头部耳机不晃动为宜。
2.通话时,将耳机麦克风朝向嘴部可使通话更清晰。
3.请正确侧戴左右耳机,入耳后使其稳固贴合耳廓及出音嘴对准耳道 4.可在APP内选择开/关入耳检测功能

一键进入配对模式

1. 耳机已经与手机配对。 2. 耳机放盒子里,打开充电盒盖子,长按充电盒按键3秒至充 电盒绿灯闪3下,耳机断开与手机的连接,进入配对模式。



单耳机使用模式

1. 双耳有配对历史、且在关机状态下,长按任一耳机触控面 板约2秒开机,等5秒后耳机进入配对状态(蓝灯闪烁) 2. 打开手机蓝牙搜索配对名,选择 QCY-T8 点击连接。

给耳机充电

耳机放入充电盒,盖上盖子,耳机会自动关机,进入充电状态。

未充满电,充电盒红灯长亮;充满电,充电盒绿灯长亮。

产品参数

电池类型:聚合物锂离子电池 耳机电池容量: 3.7V 35mAh 充电盒电池容量: 3.7V 380mAh 充电盒输入参数: 5V == 400mA 支持协议: HSP/HFP/A2DP/AVRCP

- 1.Q:怎么只能听一个? A:将两只耳机放回充电舱,重新取出查看是否恢复双耳模式, 如未恢复重置耳机即可解决。
- 2.Q:手机提示无法连接怎么解决? A:将手机上的配对记录删除,删除后重新进行搜索信号连接 即可。
- 3.Q:怎么听歌/通话没声音? A:安卓在手机连接记录的右边有个设置图标,点击进入,将两个音频违项或消勾,违重新选择。苹果在设置通用辅助功能进入音频通话方法,选择自动,如来就是自动,就换其他选项,然后选择自动,如未恢复,删除配对记录重新尝试。
- 4.Q:怎么视频/游戏有延迟? A:受使用环境、网络、手机编解码速度的影响,会造成手机传 送音频数据到耳机时造成不同程度的延迟。
- 5.Q:怎么卡顿/斯续? A:亲,如果使用时有大量的 Wi-Fi 连接,4G 信号、大功率电器 等等产生干扰,可能会出现卡顿、斯续的情况,换个环境或 者重新配对连接下就可以解决了。

若有售后服务需求,请联系客服

制造商:东莞市和乐电子有限公司 地址:广东省东莞市道滘镇大岭丫工业区 (粤晖路大岭丫段5号)

产品中有害物质的名称及含量

有害物质											
部	牛名称	铅 Pb	汞 Hg	镉 Cd	六价铬 Cr (M)	多溴 联苯 PBB	多溴 二苯醚 PBDE	邻苯二 甲酸二 异丁酯 DIBP	邻苯二 甲酸 (2-乙酯) DEHP	邻苯二甲酸二丁酯 DBP	邻苯二 甲酸丁 苄酯 BBP
耳	机主体	Х	0	0	0	0	0	0	0	0	0
电	池	0	0	0	0	0	0	0	0	0	0
耳	套	0	0	0	0	0	0	0	0	0	0
配	件	0	0	0	0	0	0	0	0	0	0
充	电线	X	0	0	0	0	0	0	0	0	0

- 本表格依据SJ/T11364的规定编制
- O:表示该有害物质在部件所有均匀材质中的含量均在 (EU)2015/863规定的限量要求以下。 X:表示该有害物质至少在该部件的某一均质材料中的含量超出
- (EU)2015/863规定的限量要求,但目前行业无成熟的替代方案, 在豁免范围仍符合欧盟ROHS指令的环保要求。



*

如本手册所述,在正常使用条件下,本产品的环保使用期限为10年。 在此期间,产品不会泄露任何危险物质,本产品可以回收,必须按 照当地法规处理。







- 1. 使用产品前请仔细阅读本使用说明书并请妥善保管;
- 2. 首次使用时,请先将本产品充满电; 3. 如果产品长期(超过2个星期)不用,请对其充电;
- 4. 必须选择正规厂家生产且经过国家CCC认证的充电器; 5. 若手机无法搜索蓝牙耳机,请确认蓝牙耳机是否处于"配对 模式",若长时间未进行配对或连接,蓝牙耳机配对功能将关闭,请重新开启蓝牙耳机至"配对模式";若手机程序出错,请重启

手机;若蓝牙耳机程序出错,请重启蓝牙耳机或者恢复出厂

- 请勿以任何理由拆除或维修改装耳机, 否则可能会导致起火, 电子击穿甚至彻底损坏本产品; 请勿将产品置于温度过低或过高(0℃以下或45℃以上的环
- 请避免靠近儿童或动物的眼睛使用产品指示灯;
- 请勿在雷暴天气下使用该产品,雷暴可导致本产品工作不正常, 并增加触电的危险; 请勿用油及其他挥发性液体擦拭本产品;

注意:长时间使用耳机可能会造成听力损害,请合理安排使用

本耳机不支持输出超过2A的充电座给耳机充电,否则会 损害耳机本体。

Overview CCAQCY-T8 TWS Smart Earbuds \bigcirc For better using experience, please scar QCY app before start-up. - TYPE-C USB charging port

操作

放入充电盒,关盖(有霍尔开关功能)

1.双击; 2.取下任置耳机音乐暂停,15秒内戴上耳 机,音乐继续播放(取下15秒后回到初始 状态,需先手动轻按触控面板两次或点击 手机播放

轻按左/右触控面板2秒,切换下一曲

轻按触控面板两次接听/结束通话

长按触控面板5秒, 灯灭

轻按触控面板1秒释放


轻按触控面板三次

How to Connect

First time connectivity:

Switch connected device:

1. Turn off phoneA's Bluetooth faculty and earbuds will auto disconnect and turn connectable." 2. On phoneB, search for QCY-T8 and tap to con



Factory Setting

ase refer the following methods to fix connectivity errors

Method 1:

1. Delete connectivity record on phone, if any.

2. Take out both earbuds from case and keep touching both of the panels for 5s or until LED glows red for 2s to power off









How to Wear

1. Rotate earbud and pop it into your ear then shake head to check wearing stability. ' 2. Please adjust Mic towards your mouth to gain better calling experience."
3.Please wear earbuds properly, making sure they fit in firmly and sound holes are inside ear channels
4.You may turn on/off In-ear Detection in APP

One Press to Enter Pairing Mode

1.Earbuds have been connected with phone.
2.Pop earbuds into case. Open lid and hold charging case button for 3s or until LED on case blinks green 3 times. Earbuds will then disconnect to phone and enter pairing



Mono Mode

1.Earbuds were paired before. Keep touching panel on either earbud for 2s to power on them. They will auto turn connectable in 5s(LED will blink blue).

2. On phone, search for QCY-T8 and tap to connect the

Charge the Earbuds

Push earbuds into the case and close the lid. Earbuds will auto turn off and to be charged.

Charge the Case

LED of the case will glow solid red when charging and turn green once topped up.

Model: TWS Smart Earbuds
Model: TWS Smart Earbuds
Bluetooth version: V5.0
Charging time: approx. 2hr
Clark time: approx. 3.5hr
Clark time: approx. 4.5hr
Clark time: approx. 4

Functions

Functions	Current status	Operation	LED	Prompt
Power-on	Earbuds are not in the case	Keep touching the panel for 2s		e TONE
rower-on	Earbuds are in the case with its lid closed (the case is within power)	Open the lid	LED blinks blue	
Power-off	Case is within power	Push earbuds into case and close the lid	LED glows solid red when charging	\
Power-on	/	Keep touching the panel for 5s	LED glows red for 2s	TONE
Answer/end call	Incoming call/ calling	Double tap the panel to answer/end the call	\	TONE
Ignore call	Incoming call	Keep touching the panel for 1s	\	TONE
Voice assistant	Connected	Triple tap the panel	\	TONE
Music pause/ resume playing	Playing	Double tap Put off either earbud to pause and put it on in 15s to resume playing	\	\
Skip track forward	Playing	Keep touching either panel for 2s to skip track forward	\	\

Warranty Card

12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service:
Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card

Model Number:		
Date of Purchasing:		
User's Name:		
User's Phone:		
User's Address:		
Shop's Name:		
Shop's Address:		

Free exchange service will not be accessed under following circumstances:

1. Damages caused unauthorized disassembly.

2. Defects or physical damages caused by leaking or dropping off.

3. Damages by act of God.Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

FCC Statement


imits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

10)



- This form is made by SJ/T 11364 regulation.
 O: means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation.
 X: means that hazardous substance content in at least, one certain homogeneous material of this part is beyond the limits of (EU) 2015/863 regulation, but there is no mature alternative in the industry at present, it still conforms to the EU ROHS Directive in the scope of exemption.
- Notes: Please arrange using time properly as your hearing may be damaged by using the device for a long time. Manufacturer: Dongguan Hele Electronics Co., Ltd.
 Address: Daojiao Town, Dongguan City, Guangdong, China

- carefully and keep it for future references.

 2. The headset need to be fully charged prior to first-time use. If the headset is left unused for over two weeks, please recharge it periodically.

 4. Please use the chargers made by qualified manufacturer.
- 4. Please use the chargers made by qualined manufacturer. S. If the headset cannot be found by your phone, please check whether it is in pairing mode; if left unconnected for a long while, the headset will exit pairing mode, please re-enter the mode; if a procedure error of your phone occurs, reboot it, if a procedure error of the headsetoccurs, reboot or reset it.

6. Keep the headset dry.

Caveats

1. Never disassemble or modify your headset for any
to recide our damages and danger. reasons to avoid any damages and danger. 2. Do not store the headset in extreme temperatures (under 0°C or over 45°C).

3. Avoid using the indicator close to the eyes of children or animals.

4. Do not use this headset during a thunderstorm to avoid irregular function and increased risk of electricshock.

5. Do not use harsh chemicals or strong detergents to

