



# Connect SDK 4.0.3.0 GA

## Simplicity SDK Suite 2024.12.3

### August 6, 2025

The Connect SDK is a complete software development suite for proprietary wireless applications that was previously part of the Proprietary SDK. Starting with the Connect SDK 4.0.0.0 release, Proprietary SDK is split into RAIL SDK and Connect SDK.

Connect SDK uses Silicon Labs Connect, an IEEE 802.15.4-based networking stack designed for customizable broad-based proprietary wireless networking solutions that require low power consumption and operates in either the sub-GHz or 2.4 GHz frequency bands. The solution is targeted towards simple network topologies.

Connect SDK is supplied with extensive documentation and sample applications. All examples are provided in source code within the Connect SDK sample applications.

These release notes cover SDK version(s):

4.0.3.0 GA released August 6, 2025 (Underlying platform changes only)  
4.0.2.0 GA released April 1, 2025 (Underlying platform changes only)  
4.0.1.0 GA released February 5, 2025 (Underlying platform changes only)  
4.0.0.0 GA released December 16, 2024



#### CONNECT APPS AND STACK KEY FEATURES

- PSA Crypto hardware acceleration for payload encryption enabled in Connect stack on Series-2 parts
- Connect stack and Connect SDK enabled on BRD4276A radio board with EFR32FG25 and SKY66122-11 frontend module for high TX power applications

## Compatibility and Use Notices

For information about security updates and notices, see the Security chapter of the Platform Release Notes installed with this SDK or on the TECH DOCS tab on <https://www.silabs.com/developers/flex-sdk-connect-networking-stack>. Silicon Labs also strongly recommends that you subscribe to Security Advisories for up-to-date information. For instructions, or if you are new to the Silicon Labs Flex SDK, see [Using This Release](#).

### Compatible Compilers:

IAR Embedded Workbench for ARM (IAR-EWARM) version 9.40.1

- Using wine to build with the IarBuild.exe command line utility or IAR Embedded Workbench GUI on macOS or Linux could result in incorrect files being used due to collisions in wine's hashing algorithm for generating short file names.
- Customers on macOS or Linux are advised not to build with IAR outside of Simplicity Studio. Customers who do should carefully verify that the correct files are being used.

GCC (The GNU Compiler Collection) version 12.2.1, provided with Simplicity Studio.



Contents

1 Connect Applications.....3

1.1 New Items.....3

1.2 Improvements.....3

1.3 Fixed Issues .....3

1.4 Known Issues in the Current Release .....3

1.5 Deprecated Items .....3

1.6 Removed Items .....3

2 Connect Stack.....4

2.1 New Items.....4

2.2 Improvements.....4

2.3 Fixed Issues .....4

2.4 Known Issues in the Current Release .....4

2.5 Deprecated Items .....4

2.6 Removed Items .....4

3 Using This Release.....5

3.1 Installation and Use .....5

3.2 Security Information.....5

3.3 Support.....6

3.4 SDK Release and Maintenance Policy .....6

# 1 Connect Applications

## 1.1 New Items

### Added in release 4.0.0.0

- simplicity\_sdk/app/flex is split into two:
  - simplicity\_sdk/app/rail (RAIL SDK)
  - simplicity\_sdk/app/connect (CONNECT SDK)

## 1.2 Improvements

### Changed in release 4.0.0.0

None.

## 1.3 Fixed Issues

### Fixed in release 4.0.0.0

None.

## 1.4 Known Issues in the Current Release

Issues in bold were added since the previous release. If you have missed a release, recent release notes are available on the TECH DOCS tab on <https://www.silabs.com/developers/flex-sdk-connect-networking-stack>.

| ID #    | Description                                                                                                       | Workaround |
|---------|-------------------------------------------------------------------------------------------------------------------|------------|
| 652925  | EFR32XG21 is not supported for "Flex (Connect) - SoC Light Example DMP" and "Flex (Connect) - SoC Switch Example" |            |
| 1139850 | DMP instabilities with XG27                                                                                       |            |

## 1.5 Deprecated Items

### Deprecated in release 4.0.0.0

Flex SDK Flex folder is deprecated and will be removed. It has been split into Rail folder for RAIL SDK and Connect folder for Connect SDK..

## 1.6 Removed Items

### Removed in release 4.0.0.0

None.

## 2 Connect Stack

### 2.1 New Items

#### Added in release 4.0.0.0

- The CCM\* operations realized to encrypt and decrypt the stack communications are now performed by default using PSA Crypto API. Until now, the stack used its own implementation of CCM\* and only used PSA Crypto API to perform AES block calculations. Two new components, “**AES Security (Library)**” and “**AES Security (Library) | Legacy**”, have been added, allowing the selection of one or the other of the implementations. The two components are compatible and can be installed at the same time. Refer to <https://docs.silabs.com/connect-stack/4.0.0/connect-security-key-migration/> for further information.

### 2.2 Improvements

#### Changed in release 4.0.0.0

None.

### 2.3 Fixed Issues

#### Fixed in release 4.0.0.0

None.

### 2.4 Known Issues in the Current Release

Issues in bold were added since the previous release. If you have missed a release, recent release notes are available on the TECH DOCS tab on <https://www.silabs.com/developers/gecko-software-development-kit>.

| ID #   | Description                                                                                                                                                                                                                                                     | Workaround                                                                                                                                                                                                |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | When running the RAIL Multiprotocol Library (used for example when running DMP Connect+BLE), IR Calibration is not performed because of a known issue in the RAIL Multiprotocol Library. As result, there is an RX sensitivity loss in the order of 3 or 4 dBm. |                                                                                                                                                                                                           |
| 501561 | In the Legacy HAL component, the PA configuration is hard-coded regardless of the user or board settings.                                                                                                                                                       | Until this is changed to properly pull from the configuration header, the file ember-phy.c in the user's project will need to be modified by hand to reflect the desired PA mode, voltage, and ramp time. |

### 2.5 Deprecated Items

#### Deprecated in release 4.0.0.0

None.

### 2.6 Removed Items

#### Removed in release 4.0.0.0

None.

## 3 Using This Release

This release contains the following:

- Radio Abstraction Interface Layer (RAIL) stack library
- Connect Stack Library
- RAIL and Connect Sample Applications
- RAIL and Connect Components and Application Framework

This SDK depends on the Simplicity Platform. The Simplicity Platform code provides functionality that supports protocol plugins and APIs in the form of drivers and other lower layer features that interact directly with Silicon Labs chips and modules. Simplicity Platform components include EMLIB, EMDRV, RAIL Library, NVM3, and mbedTLS. Simplicity Platform release notes are available through Simplicity Studio's Documentation tab.

For more information about the Flex SDK v3.x see [UG103.13: RAIL Fundamentals](#) and [UG103.12: Silicon Labs Connect Fundamentals](#). If you are a first time user, see [QSG168: Proprietary Flex SDK v3.x Quick Start Guide](#).

### 3.1 Installation and Use

The Proprietary Flex SDK is provided as part of the Simplicity SDK, the suite of Silicon Labs SDKs. To quickly get started with the Simplicity SDK, install [Simplicity Studio 5](#), which will set up your development environment and walk you through Simplicity SDK installation. Simplicity Studio 5 includes everything needed for IoT product development with Silicon Labs devices, including a resource and project launcher, software configuration tools, full IDE with GNU toolchain, and analysis tools. Installation instructions are provided in the online [Simplicity Studio 5 User's Guide](#).

Alternatively, Simplicity SDK may be installed manually by downloading or cloning the latest from GitHub. See [https://github.com/SiliconLabs/simplicity\\_sdk](https://github.com/SiliconLabs/simplicity_sdk) for more information.

Simplicity Studio installs the GSDK by default in:

- (Windows): C:\Users\<NAME>\SimplicityStudio\SDKs\simplicity\_sdk
- (MacOS): /Users/<NAME>/SimplicityStudio/SDKs/simplicity\_sdk

Documentation specific to the SDK version is installed with the SDK. Additional information can often be found in the [knowledge base articles \(KBAs\)](#). API references and other information about this and earlier releases is available on <https://docs.silabs.com/>.

### 3.2 Security Information

#### Secure Vault Integration

When deployed to Secure Vault High devices, sensitive keys are protected using the Secure Vault Key Management functionality. The following table shows the protected keys and their storage protection characteristics.

| Wrapped Key        | Exportable / Non-Exportable | Notes                               |
|--------------------|-----------------------------|-------------------------------------|
| Thread Master Key  | Exportable                  | Must be exportable to form the TLVs |
| PSKc               | Exportable                  | Must be exportable to form the TLVs |
| Key Encryption Key | Exportable                  | Must be exportable to form the TLVs |
| MLE Key            | Non-Exportable              |                                     |
| Temporary MLE Key  | Non-Exportable              |                                     |
| MAC Previous Key   | Non-Exportable              |                                     |
| MAC Current Key    | Non-Exportable              |                                     |
| MAC Next Key       | Non-Exportable              |                                     |

Wrapped keys that are marked as "Non-Exportable" can be used but cannot be viewed or shared at runtime.

Wrapped keys that are marked as "Exportable" can be used or shared at runtime but remain encrypted while stored in flash.

For more information on Secure Vault Key Management functionality, see [AN1271: Secure Key Storage](#).

## Security Advisories

To subscribe to Security Advisories, log in to the Silicon Labs customer portal, then select **Account Home**. Click **HOME** to go to the portal home page and then click the **Manage Notifications** tile. Make sure that 'Software/Security Advisory Notices & Product Change Notices (PCNs)' is checked, and that you are subscribed at minimum for your platform and protocol. Click **Save** to save any changes.

The following figure is an example:

The screenshot shows the 'Update Preference' form in the Silicon Labs customer portal. The form is titled 'Update Preference' and has a sub-header 'WHAT EMAILS WOULD YOU LIKE TO RECEIVE?'. Under this section, there are two groups of checkboxes: 'Newsletters' and 'Product Specific Notifications'. The 'Product Specific Notifications' group has a checkbox for 'Software/Security Advisory Notices & Product Change Notices (PCNs)' which is checked and highlighted with a red box. Below this, there is a section titled 'SELECT THE PRODUCTS TO RECEIVE UPDATES FOR'. This section contains a grid of checkboxes for various product categories. The 'Microcontrollers' category is checked and highlighted with a red box, and the 'Wireless' category is also checked and highlighted with a red box. The 'Microcontrollers' sub-category '32-bit MCUs' is checked, and the 'Wireless' sub-category 'Proprietary' is checked.

## 3.3 Support

Development Kit customers are eligible for training and technical support. Use the [Silicon Labs Flex web page](#) to obtain information about all Silicon Labs Thread products and services, and to sign up for product support.

You can contact Silicon Laboratories support at <http://www.silabs.com/support>.

## 3.4 SDK Release and Maintenance Policy

For details, see [SDK Release and Maintenance Policy](#).

# Simplicity Studio

One-click access to MCU and wireless tools, documentation, software, source code libraries & more. Available for Windows, Mac and Linux!



**IoT Portfolio**  
[www.silabs.com/loT](http://www.silabs.com/loT)



**SW/HW**  
[www.silabs.com/simplicity](http://www.silabs.com/simplicity)



**Quality**  
[www.silabs.com/quality](http://www.silabs.com/quality)



**Support & Community**  
[www.silabs.com/community](http://www.silabs.com/community)

## Disclaimer

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice to the product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Without prior notification, Silicon Labs may update product firmware during the manufacturing process for security or reliability reasons. Such changes will not alter the specifications or the performance of the product. Silicon Labs shall have no liability for the consequences of use of the information supplied in this document. This document does not imply or expressly grant any license to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any FDA Class III devices, applications for which FDA premarket approval is required or Life Support Systems without the specific written consent of Silicon Labs. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons. Silicon Labs disclaims all express and implied warranties and shall not be responsible or liable for any injuries or damages related to use of a Silicon Labs product in such unauthorized applications.

## Trademark Information

Silicon Laboratories Inc.<sup>®</sup>, Silicon Laboratories<sup>®</sup>, Silicon Labs<sup>®</sup>, SiLabs<sup>®</sup> and the Silicon Labs logo<sup>®</sup>, Bluegiga<sup>®</sup>, Bluegiga Logo<sup>®</sup>, EFM<sup>®</sup>, EFM32<sup>®</sup>, EFR, Ember<sup>®</sup>, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Redpine Signals<sup>®</sup>, WiSeConnect, n-Link, EZLink<sup>®</sup>, EZRadio<sup>®</sup>, EZRadioPRO<sup>®</sup>, Gecko<sup>®</sup>, Gecko OS, Gecko OS Studio, Precision32<sup>®</sup>, Simplicity Studio<sup>®</sup>, Telegesis, the Telegesis Logo<sup>®</sup>, USBXpress<sup>®</sup>, Zentri, the Zentri logo and Zentri DMS, Z-Wave<sup>®</sup>, and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other products or brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc.  
400 West Cesar Chavez  
Austin, TX 78701  
USA

[www.silabs.com](http://www.silabs.com)