



INSTRUCTIONS FOR REPLACING REMOTE CONTROL/POWER SWITCH WITH MANUAL ON/OFF SWITCH ON HANDWARMER (PN5136)

1. REMOVE 24VDC POWER SWITCH FROM BATTERY
2. CONNECT NEW POWER HARNESS TO BATTERY AND CONNECT TO NEW ON/OFF SWITCH
3. MOUNT ON/OFF SWITCH TO HANDWARMER MOUNTING PLATE
4. PLUG ON/OFF SWITCH INTO HEATER BOX
5. ASSEMBLY COMPLETE AND READY TO GO



