INSTRUCTIONS DO NOT PRINT THIS LAYER

Dimensions: 3.7in (w) x 2.65in (h)

PRINT BACK TO BACK



Specifications:

Bluetooth® distance: 10m

Battery capacity: 30mAh

Built-in lithium battery

FRONT

Pairing name: "Ring Phone Remote" 000000 One (1) Ring sized phone remote

1.03in. x 1.26in. x 0.45in

(2.63cm x 3.22cm x 1.16cm),

One (1) Charging Cable 5.85in. (14.85cm), One (1) User Manual.

Functions:

Scroll up and down.

Take remote selfies and record videos.

Turn pages on most e-book apps.

Rechargeable battery that lasts up to 6 months on a fully charge. Like images and videos on most social media apps.



Charge it with DC5V Micro USB charging cable.

ON: Long press the "POWER" key for 2 seconds.

enter to standby mode.

The indicator light will flash 1 time, the light

will go off and the ring will automatically

During charging the indicator light in red always and turn off when it is fully charged.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no augrantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

· Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "Zeikos" is under license. Other trademarks and trade names are those of their respective owners.

Distributed By: 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 MADE IN CHINA

Bluetooth


RING-SIZED PHONE REMOTE

Scroll, like, record & more


INSTRUCTIONS MANUAL

Please keep for future reference





Back



OFF: Long press the "POWER" key for 2 seconds. The indicator light will flash 2 times, and your device will be off.

• • • ★ • • • Bluetooth® connection

- · Go to your device settings and turn on the Bluetooth function.
- From the list of available devices select: "Ring Phone Remote"
- A Bluetooth pairing request might appear on you screen go ahead and confirm the pairing.

If the pairing is successful your phone will display "connected" on you list of Bluetooth devices.

Camera Function

• Open your devices camera.

For most devices

• To take photos:

(U) Short press "Power" key

To record Videos:

Short press "Power" key to start.
Short press "Power" key to finish

If the Ring Phone Remote doesn't work as above, please follow the instructions below. For some devices

1-Long press ►I Play button until the indicator light flashes to start the cursor adjustment.

2-Short press ▲ up, ▼ down, ▶ right or ◄ left button to adjust the direction of cursor to align the cursor with shutter.

3-Short press ▶ Play button to finish the adjustment, when the final position of the cursoris inside the shutter button. 4-Short press (1) Power button to start/finish photo/video





The final position of the cursor should be inside the shutter

Low Power: When the battery voltage is lower than 3.2V, the indicator flash red light. When the battery voltage is lower than 3.0V, it will automatically power off.



scroll up

(short press

For iPhones & iPads (iOS devices)

scroll down

(short press)

The AssistiveTouch function must be turned on. To turn on AssitiveTouch follow the next steps:

Settings > Accessibility> Touch > AssistiveTouch > AssistiveTouch





(short press)







Short Press: Pause or Play Quick double click: Like