


KINGONE iPad Pencil English Manual



- ① Power Button
- ② Indicator Light
- ③ Magnetic Surface (Plane)
- ④ Pen Tip (Removable)

Really appreciate for purchasing this product.
In order to use the product more smoothly, please read the following usage guidelines.

User's guidance


If you have an Apple pencil, please disconnect the Apple pencil.
iPad [Settings] - [Apple pencil] - [Apple pencil drawing only] settings are invalid.

1. Drive Mode

Long press the switch key above to turn on/off the power to use.
Basic writing functions do not require Bluetooth connection, and some functions require Bluetooth connection. (Please refer to point 4 for the difference between whether or not to connect to Bluetooth)


2. Charging method

Place it on the side of the iPad to charge.
Enable wireless charging.



3. How to connect to Bluetooth

Open the Bluetooth settings, see the device name of [K-PEN], and click Connect.



4. The difference between whether to connect to Bluetooth

(1) The following functions can be realized regardless of whether Bluetooth is connected or not.

Drive Mode
A Palm Rejection Function
B Tilt Sensing
C Automatically Sleep after 5 minutes no use
D Magnetic Attraction Function
E Quick Screenshot
G Handwritten Text
Charging Mode (Wireless Charging)

Note: To use E, F, G, iPad needs to be updated to a version after iOS 14.

(2) The function that needs to be connected to Bluetooth

Press the switch button at the top twice to return to the [Recently used APP interface]

Press the switch key at the top once to return to the main screen

On the home screen or lock screen, tap the pen tip on the home screen twice to open [Memo]

Check the remaining battery





[Recently used APP interface]

Note: The pen pressure sensing function is only available with genuine Apple pencils.
Corresponding software for tilt sensing function: SketchBook, Procreate, Paper, Notes, Art Set

(3) How to check the remaining battery power


Long press the main interface and swipe right. Add a battery in the search window, and you can confirm the instant remaining battery power of the pen.

How to check the remaining battery power



5. How to replace the nib

Pinch it with your fingers and rotate it gently for easy disassembly.



6. Indicator display

Working Status	Greenlight	Battery 100%-20%
	Red light	Battery 20% - 0%
Charging	Flashing green	100% - 20% battery
	Flashing red light	battery 20% - 0%
Finished Charging	Green Light	Battery Reaches 100%

※Notice

When fully charged, the LED stops flashing, and the green light stays on for 5 minutes and then turns off.
During use, if the product is abnormal, please press and hold the power button for 5 seconds to restart.

7. Applicable Models

iPad mini 6th generation
iPad Air (4th/5th generation)
iPad Pro 11 inch (1st/2nd/3rd generation)
iPad Pro 12.9 inch (3rd/4th/5th generation)
The magnetic attraction only corresponds to the iPad.
Please confirm carefully.

8. Precautions for use

The company is not responsible for direct or indirect damage caused by improper use of the product, please be aware.

- ① Please do not use it for anything other than iPad touch.
- ② Please do not disassemble, repair or modify the pen for iPad.
- ③ Please do not hit the iPad pen with force.
- ④ Please do not use liquid such as water. Please do not place it in direct sunlight.
- ⑤ Keep out of the reach of children. In addition, when children use it, be sure to have an accompanying person, read the instructions carefully, and use it correctly.

9. Warranty

This product has a warranty, if you have any questions or quality problems during use, please feel free to contact us. We will solve it until you are satisfied.

Email: ind-support@kingoneglobal.com