

SVEN®

Wired Keyboard

USER MANUAL



KB-E5000

www.sven.fi

Congratulations on your purchase of the Sven Keyboard!

Please read this User's Manual before using the unit and retain this User's Manual in a safe place for future reference.

COPYRIGHT

© SVEN PTE. LTD. Version 1.0 (V 1.0). This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on 'as is' terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

UNPACKING

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

SPECIAL FEATURES

- 5 shortcut keys.
- 12 media (FN) keys.
- Classic layout.

PACKAGE CONTENTS

- Wired keyboard — 1 pc.
- User's Manual — 1 pc.
- Warranty card — 1 pc.

SYSTEM REQUIREMENTS

- Windows.
- Free USB port.

Technical support is on www.sven.fi.

DESCRIPTION OF SHORTCUT KEYS FUNCTIONS

Fn + F1	Start media player		Start calculator
Fn + F2	Volume down	Web 	Go to previous internet page
Fn + F3	Volume up	Web 	Go to next internet page
Fn + F4	Mute/Unmute		
Fn + F5	Play previous track	Web 	Start web searching
Fn + F6	Play next track	Web 	Stop web page loading
Fn + F7	Play/Pause		
Fn + F8	Stop playing		
Fn + F9	Open homepage		
Fn + F10	Start e-mail app		
Fn + F11	Open "My computer"		
Fn + F12	Open Favorites		

INSTALLATION

- Connect the keyboard to an available USB port of your PC.
- Installation of keyboard is automatic after its connection to USB port of PC.

TROUBLESHOOTING

Problem	Solution
The keyboard is not working.	1. Check whether the batteries have been installed correctly. If necessary, replace the batteries with new ones matching the polarity. 2. Pull out the USB receiver and insert it back, make sure that it is not damaged. 3. We recommend that you address your nearest service center.

If none of the above methods can solve the problem, please seek professional advice at your nearest service center. Never attempt to repair the product yourself.

8. TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys	109
Keyboard layout	Eng/Rus/Ukr
OS compatibility	Windows
Interface	USB
Keyboard dimensions (L × W × H), mm	430 × 118 × 22
Weight, g	412

Notes. Technical specifications given in this table are supplemental information and cannot give occasion to claims. Technical specifications are subject to change without notice due to the improvement of SVEN production.

Wired Keyboard

SVEN[®]

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447.
Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.



1B0219

KB-E5000