

### CHF WATCH APP




SCAN QR CODE TO INSTALL THE CHF WATCH APP

### cmf by NOTHING WATCH PRO 2


V1 MODEL: D098

### PRODUCT OVERVIEW



### CHANGE BEZEL

Remove the bezel. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.




Install bezel. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



### USER GUIDE

### PAIRING AND CONNECTION

Enter Pairing Mode. Press and hold the Function button on the side to enter pairing mode.



Download CHF Watch App. Scan the QR code or search for CHF Watch in Google Play Store (Android) or App Store (iOS) and download.



Set up and pair. Turn on Bluetooth on the CHF Watch app to add device. Select the watch on nearby devices, or scan the QR code on the watch screen to pair with the watch.



Pairing complete. Select the watch on nearby devices, or scan the QR code on the watch screen to pair with the watch.




### OPERATIONS


On the home screen. Swipe down to expand Quick Settings. Swipe up to see notifications. Swipe left to see widgets. Press right to see widgets or return to the previous page and hold to change the watch face.




Cover watch with palm. Turn off the screen.




Rotate up. Scroll up or previous interface.



Rotate down. Scroll down or next interface.




Press once. Tap the watch. Press and hold. Press and hold for 10 seconds to force restart.



Gesture control. Gesture Control is turned off by default. If you need to turn it on, please connect the CHF Watch app to the watch, and after connecting, enter the Gesture Control Function to turn on and set related options.



### PRODUKTÜBERSICHT



Aufladen. The CHF Watch is charged by placing it on the charging dock. Please ensure the watch is placed correctly on the dock. The charging dock is included in the package. Please refer to the user manual for more details.



### WECHSEL DER LEITETTE

Entfernen Sie die Leinette. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



Installieren der Leinette. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



### KOPPLUNG UND VERBINDUNG

Einrichten und Kopplung. Scan the QR code or search for CHF Watch in Google Play Store (Android) or App Store (iOS) and download.




Pairing complete. Select the watch on nearby devices, or scan the QR code on the watch screen to pair with the watch.



### BETRIEBS

Nach unten wischen, um die Schnell-Einstellungen zu sehen. Nach oben wischen, um Benachrichtigungen zu sehen. Nach links wischen, um Widgets zu sehen. Nach rechts wischen, um Widgets zu sehen oder zur vorherigen Seite zurückzukehren. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



Nach oben drücken. Nach unten drücken. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.




Einstellen drücken. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



SCHNELLE GESTEN. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### DESCRIPCIÓN GENERAL DEL PRODUCTO



Carga. Place the watch on the charging dock. Please ensure the watch is placed correctly on the dock. The charging dock is included in the package. Please refer to the user manual for more details.



### CAMBIAR BISEL

Quitar el bisel. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.




Instalar bisel. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



### EMPAJEAMIENTO Y CONEXIÓN

Accede al modo de emparejamiento. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



Descarga la aplicación CHF Watch. Scan the QR code or search for CHF Watch in Google Play Store (Android) or App Store (iOS) and download.




Configuración y emparejamiento. Select the watch on nearby devices, or scan the QR code on the watch screen to pair with the watch.




### OPERACIONES

En la pantalla de inicio. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.




Deslizar hacia arriba. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



Deslizar hacia abajo. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



Presionar rápido. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



GESTOS RÁPIDOS. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### 製品の概要



充電する. Place the watch on the charging dock. Please ensure the watch is placed correctly on the dock. The charging dock is included in the package. Please refer to the user manual for more details.



### ベゼルの変更

ベゼルの取り外し. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



ベゼルの取り付け. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



### ペアリングと接続


ペアリングモードに入る. Press the bezel and thumb on both sides of the bezel to press over and apply the anti-static brush to the bezel. Hold it counter-clockwise at an angle below the display with a little force until it can be lifted out.



CHF Watch アプリをダウンロード. Scan the QR code or search for CHF Watch in Google Play Store (Android) or App Store (iOS) and download.



設定と接続. Select the watch on nearby devices, or scan the QR code on the watch screen to pair with the watch.



### نظرة عامة على المنتج




الشحن. Place the watch on the charging dock. Please ensure the watch is placed correctly on the dock. The charging dock is included in the package. Please refer to the user manual for more details.



### تغيير الإخطار

تغيير الإخطار. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### الأقران والاتصال

الأقران والاتصال. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



CHF Watch تطبيق. Scan the QR code or search for CHF Watch in Google Play Store (Android) or App Store (iOS) and download.



التوصيل. Select the watch on nearby devices, or scan the QR code on the watch screen to pair with the watch.



### الوظائف

الوظائف. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### प्रोब्लम सोल्यूशन्स

प्रोब्लम सोल्यूशन्स. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### ब्याटरी

ब्याटरी. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### पैरिंग और कनेक्शन

पैरिंग और कनेक्शन. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



CHF Watch ऐप. Scan the QR code or search for CHF Watch in Google Play Store (Android) or App Store (iOS) and download.




कनेक्शन. Select the watch on nearby devices, or scan the QR code on the watch screen to pair with the watch.



### संचालन

संचालन. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### बैटरी चार्जिंग

बैटरी चार्जिंग. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### सुपर बैटरी

सुपर बैटरी. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.




### संचालन

संचालन. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### बैटरी चार्जिंग

बैटरी चार्जिंग. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.




### संचालन

संचालन. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### बैटरी चार्जिंग

बैटरी चार्जिंग. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



### संचालन

संचालन. Wischen Sie nach rechts, um das Zurückfließen zu aktivieren.



SCAN QR CODE TO SEE THE USER GUIDE IN OTHER LANGUAGES.