






OLED55C2AUA
OLED55C2PUA

OLED65C2AUA
OLED65C2PUA


OLED77C2AUA
OLED77C2PUA




The remote control may vary depending on the model: The buttons on remote control may have a different name or location than the remote control shown in this manual.



The cables mentioned in this manual are not supplied with your unit.



MODELS	A		B		C		D		E		F		F-G		Power consumption (W)
OLED55C2AUA	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170
OLED55C2PUA	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170	1170
OLED65C2AUA	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710
OLED65C2PUA	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710	1710
OLED77C2AUA	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410
OLED77C2PUA	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410	2410



Warning: The image shown here is for illustrative purposes only and may be subject to change. The actual number of parts and their location may vary depending on the model.

