

INSTRUCTION MANUAL

TANK AGITATOR ATTACHMENT

Models: SG36, SG42, SG46, & SG52







STANDARD SG SERIES TANKS


ACAUTION


Be sure fluid tanks are drained before attempting the following instructions.


NOTICE

- Use white lube on hose connections.
- Securely fasten all hoses with clamps.
- Repeat all steps for the right side tank.

STEP 1: Reach through the lid opening & attach the elbow fitting (S52029 provided with the kit) to the return bulkhead. *Rotate the elbow so it's facing down towards the sump.*







35 GALLON ATTACHMENT TANK


ACAUTION

Be sure fluid tank is drained before attempting the following instructions.


NOTICE

- Use white lube on hose connections.
- Securely fasten all hoses with clamps.

STEP 1: Reach through the lid opening & attach the elbow fitting (S52029 provided with the kit) to the return bulkhead. *Rotate the elbow so it's facing down towards the sump.*



STEP 2: Connect the agitator assembly to the elbow fitting.



7 GALLON ATTACHMENT TANK


ACAUTION

Be sure fluid tank is drained before attempting the following instructions.

NOTICE

- Use white lube on hose connections.
- Securely fasten all hoses with clamps.

STEP 1: Reach through the lid opening & attach the straight fitting (S52015 provided with the kit) to the return bulkhead.



STEP 2: Drop the agitator assembly down through the lid opening & connect it to the fitting.



NOTES



Steel Green Mfg. 824 S State Road 39 Lebanon, IN 46052 (765)-481-2890 www.steelgreenmfg.com

MANUAL	MANUAL	DESCRIPTION	KIT
PART NO.	REV.		PART NO.
SGM-048	1	TANK AGITATOR ATTACHMENT	K10039