Note: Please print it on A4 paper before scanning, and then scan 5 setting codes in sequence.

Continuous Mode

Trigger Mode



