

60cm Ceramic Cooktop




FEATURES

4 Cooking Zones, Front Touch Controls,
9 Power Levels, Residual Heat Indicator, 99 Minute Timer,
Child Lock, Durable Ceramic Glass

Congratulations on your new InAlto 60cm Ceramic Cooktop!

THE CONTROL PANEL



LEGEND

1. On/Off Power button
2. Child lock button
3. Power regulating buttons
4. Timer regulating buttons

USING YOUR COOKTOP

To start cooking:

- Touch the "ON/OFF" control and all the indicators will show "--" or "--".
- Place a suitable pan on the cooking zone that you wish to use. Make sure the bottom of the pan and the surface of the cooking zone are clean and dry.
- Touching the heating zone selection control, and the indicator next to the key will flash.
- Select a heat setting by touching the "-" or "+" button controls. The options range from 0–9. You can modify this temperature at any time during cooking. If you don't choose a heat setting within 1 minute, the induction cooktop will automatically switch off. You will need to repeat the previous steps.

To end cooking:

- Turn the whole cooktop off by pressing the "ON/OFF" button.
- Alternatively you can select your desired zone and use the "-" or "+" button controls to change the temperature of this zone to zero "0". After a cooking zone is turned off, the corresponding indicator will show "H" until the zone has cooled to a safe temperature.

Note: For further operation instructions refer to pages 11–13 of your user manual.

DETAILS

Dimensions (W, D, H mm): 590 × 520 × 51
 Built-in Dimensions (W, D mm): 560 × 480
 Warranty: 3 Years (2 + 1 on registration)

SUPPORT

Telephone: 1300 11 4357
 Email: support@residentiagroup.com.au