

 FAUX FUR EARMUFFS WIRELESS HEADPHONES INSTRUCTION MANUAL 	Table of Contents 1 Introduction.....1 2 Packaging Contents.....2 3 Connection Diagram.....2 4 How To Use.....3 4.1 General Function.....3 4.2 Pairing To Mobile Phone.....4 4.3 Charging Your Product.....5 5 Product Specification.....6 6 FAQ.....6 7 FCC Statement.....7 Battery Statement.....8	1. Introduction Congratulations, and thank you for choosing the Faux Fur Earmuffs Wireless Headphones. This manual will help you operate the Faux Fur Earmuffs Wireless Headphones, but firstly you should familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Faux Fur Earmuffs Wireless Headphones. Safety Rules 1. Please follow the rules specified in this manual closely to ensure your safety. Before using the Bluetooth headphones, we would strongly encourage you to read through this user manual. 2. In most ways of any edges, corners, surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage. 3. Do not modify, repair or disassemble the Bluetooth headphones. Doing so may void the warranty. Please refer to the warranty statement of the Bluetooth headphones. We are not responsible for any damage caused by unauthorized modification. 4. Do not use an alcohol or volatile liquid to clean the Bluetooth headphones. 5. Do not use the Bluetooth headphones if it is damaged or broken.	2. Packaging Contents  1 x Faux Fur Earmuffs Wireless Headphones 1 x USB Type-C Cable 1 x Instruction Manual 3. Connection Diagram  Power On/Off Play / Pause (H) Indicator Volume Up / Stop to Next Song Volume Down / Stop to Prev Song USB Type-C Charging Port	4. How to use 4.1 General Functions <table><thead><tr><th>Desired Result</th><th>Required Action</th></tr></thead><tbody><tr><td>Turn on & Enter the pairing mode</td><td>Press and hold the Play / Pause button for 3 seconds. After turning on the USB indicator flashes blue.</td></tr><tr><td>Pairing</td><td>Use a mobile phone with Bluetooth function or other Bluetooth device to perform necessary pairing action. After pairing, the LED indicator slowly blinks with blue.</td></tr><tr><td>Turn off</td><td>Press and hold the Play / Pause button for 3 seconds.</td></tr><tr><td>Charging</td><td>Plug the USB Type-C to the USB Type-C port. When charging, the LED indicator turns red. After full charging, the LED indicator turns off.</td></tr><tr><td>Answering a Call</td><td>Press Play / Pause button to answer phone call. Press Play / Pause button again to end call. Press and hold 3 seconds to reject call. Double click to reject call.</td></tr><tr><td>Play / Pause Music</td><td>Press Play / Pause button to play music. Press again to pause music.</td></tr></tbody></table>	Desired Result	Required Action	Turn on & Enter the pairing mode	Press and hold the Play / Pause button for 3 seconds. After turning on the USB indicator flashes blue.	Pairing	Use a mobile phone with Bluetooth function or other Bluetooth device to perform necessary pairing action. After pairing, the LED indicator slowly blinks with blue.	Turn off	Press and hold the Play / Pause button for 3 seconds.	Charging	Plug the USB Type-C to the USB Type-C port. When charging, the LED indicator turns red. After full charging, the LED indicator turns off.	Answering a Call	Press Play / Pause button to answer phone call. Press Play / Pause button again to end call. Press and hold 3 seconds to reject call. Double click to reject call.	Play / Pause Music	Press Play / Pause button to play music. Press again to pause music.
Desired Result	Required Action																	
Turn on & Enter the pairing mode	Press and hold the Play / Pause button for 3 seconds. After turning on the USB indicator flashes blue.																	
Pairing	Use a mobile phone with Bluetooth function or other Bluetooth device to perform necessary pairing action. After pairing, the LED indicator slowly blinks with blue.																	
Turn off	Press and hold the Play / Pause button for 3 seconds.																	
Charging	Plug the USB Type-C to the USB Type-C port. When charging, the LED indicator turns red. After full charging, the LED indicator turns off.																	
Answering a Call	Press Play / Pause button to answer phone call. Press Play / Pause button again to end call. Press and hold 3 seconds to reject call. Double click to reject call.																	
Play / Pause Music	Press Play / Pause button to play music. Press again to pause music.																	
4.2. Pairing to Mobile phone or other device To use your Bluetooth headphones, you must first pair your headphones with a mobile phone or other Bluetooth device. Once your Bluetooth headphones is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range. Pairing to a phone and Entertainment: • Turn on your phone and ensure the Bluetooth function is activated. • Turn on the headphones, enter the pairing mode. • Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information. • After a few seconds the phone will list the "HP-1033B" as a discover device. Select it and follow your phone's instructions to select the pairing. • Your phone will confirm the pairing, and then prompt "Yes/OK".	4.3. Charging your headphones ⚠ For your safety, please always use an appropriate 5V input charger/Adapter to charge the product. DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product. Use the USB Type-C cable accessory provided with this headphones. Connect the USB Type-C plug to the USB Type-C charging port on the headphones positioned at ① in headphones diagram on page 2. Connect the USB plug to a USB port on wall adapter to activate charging. **Make sure to keep the headphones charging for a minimum of 2 hours before initial use.  USB Plug USB Type-C Plug Warning: • You must select a qualified charger from a regular manufacturer. • You must charge the Bluetooth headphones if it has not been used for more than 3 months.	5. Product Specification Driver Diameter: 40 mm Impedance: 32 Ohms Frequency Response: 20 Hz - 20 kHz Sensitivity: 100 dB $\pm$ 3 dB Battery Capacity: Li-ion Battery 3.7 V 200 mAh Playtime: 4 - 5 Hours Charging Time: 1.5 - 2 Hours Bluetooth Range: 32 ft. (10 m) Bluetooth Version: 5.3 USB Type-C Charging Cable Included USB Type-C Charging Cable rating 3V1A Max. 6. FAQ 1. Why is there no power when the headphones is turned on? - Ans: Ensure the battery has been charged up to 1 hour for initial use. 3. There is no sound when playback. - Ans: Check the connection between headphones with phone or computer. If the connection is not established, please connect again. Make sure the headphones is paired and connected with your target phone or other master device.	7. FCC Statement FCC Declaration 1. This device complies with Part 15 of the FCC Rules. Declaration is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTES: The equipment has been evaluated to conform with the limits for unlicensed digital devices, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a regulated environment. The equipment generates, uses, and can radiate radio frequency energy which, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. RF warning statement This device has been evaluated to meet FCC RF exposure requirements. The device can be used in portable operation without restrictions.	Battery instructions for the lithium battery and charging the product - The input voltage to the product is 5V DC. - In order to charge the product in safe indoor-use conditions, please only select certified appropriate charger/adapters for charging the product. Only charge the product at ambient temperatures between 32 deg. F to 95 deg. F, and at 10% to 90% humidity. - Do not heat above 159deg. F (71deg. C), or do not expose to sunlight or blow into the device. - Do not use the device after use. - Please note that we won't take any responsibility for any wrong operation (e.g., battery higher than 3V) as the user should be aware fully in case of property, and we cannot control the operating process during the time the user using the product. - In extreme cases, damage or misuse of lithium battery pack can lead to explosion, heat generation, fire development or other development. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and may not be used by any other party without the express written permission of Bluetooth SIG, Inc. Brand HP-1033B Copyright © by 1616 Holdings, Inc. 201 Market Street, Suite 200 Philadelphia, PA 19106 Made in China FCC FCC ID: 2ACMS-HP-1033B Keep all relevant information for future reference														