User Manual

Code reader HD77





Table of contents

Specifications:	1
Set contents:	2
Features:	3
Control Codes - Reader Settings	4



Specifications:

• Warranty: 2 years

• **Light Source:** 650 -/+ 20 nm

• Processor: 32-bit ARM

• Scan Type: Bidirectional

• Scanning method: manual (push-button)

• Scan Acknowledgement: Light and Sound Signal

• Scanning speed: 300 scans per second

• Scanning width: 30 cm

• **Print Contrast:** Min 25%

• Error rate: 1/20 million

• Code memory: 100,000 codes

• Communication: Bluetooth, 2.4 GHz

• Wireless range: Bluetooth up to 10 m, radio up to 100 m

• Radio frequency: 2.4 GHz

• Button Life: 8,000,000 Times

• Laser Lifetime: 12000 hours

• Charging: via USB cable

• Charging Power Supply: 5V-400mA

Working Current: 3.5Vx40mA

Standby Current: 18A-5mA

• Working Time: 3 - 10 days

• Interface: USB

• Ingress protection: IP54

• Drop resistance: up to 2 m

• Device dimensions: 17 x 9 x 6.5 cm

• Package dimensions: 16.5 x 10 x 8 cm

• Device weight: 200 g

• Weight of the device with packaging: 260 g



• **1D Readable Codes:** UPC, EAN, Code 128, Code 39, Code 39 Full ASCII, Coda bar, Industrial 2 of 5, Interleaved 2 of 5 (ITF), Code 93, MSI, Code 11, ISBN, ISSN, China post, GS1 Databar, Code 32

Set contents:

- Wireless barcode reader
- USB cable
- USB Receiver
- Card with control codes
- Manual

Features:

- Scan speed: up to 300 scans per second
- Internal memory capacity: up to 100,000 code reads
- Wireless communication type: Bluetooth, 2.4 GHz
- Wireless range: Bluetooth up to 10 m, radio up to 100 m
- Drop resistance: up to 2 meters

Control Codes - Reader Settings



Bluetooth Mode





2.4G Mode



Cable connections included



Cable connections disabled



Factory Setting



Connect to receiver



Real-world mode



Storage mode





Data transfer



Show Memory Amount



Clearing all Data



Battery Quantity



Shut down for 50 seconds



Shut down for 2 minutes



Shut down for 5 minutes





Shut down for 30 minutes



Turn off the sound



Low tone



Mid-tone



High-pitched sound



Insert Enter



Insert double Enter





Insert TAB



Insert blank area



USB-HID



USB-VIRTUAL COM



Basic HID Mode



Turning off the reader

