
# 8BitDo

#### **Ultimate Mobile Gaming Controller**


English

# 猎户座拉伸手柄





- Press the Home button to turn on the controller
- Hold the **Home button** for 3 seconds to turn on the controller
- Hold the Home button for 6 seconds to force the controller off.



- 开机:按下 Home 键
- 关机:按住 Home 键 3 秒
- 强制关机:按住 Home 键 6 秒。

#### **Android**

Android 13 or above is required.

#### Bluetooth Connection

- 2. Hold the Pair button for 3 seconds to enter its pairing mode, the Status indicator will start to blink rapidly. (This is required for the very first time only.)
- 3. Go to your Android device's Bluetooth list and pair with [8BitDo Ultimate MG], the Status indicator will stay solid when the connection is successful.

#### **Android**



\* 要求 Android 设备系统版本为 Android 13 或更高版本。

#### 蓝牙连接

- 1. 按下 Home 键 开启手柄。
- 2 按住 配对键 3 秒至 状态指示灯 快速闪烁, 进入配对状态。(仅首次连接时需要配对)
- 3. 打开 Android 设备蓝牙,搜索 **8BitDo Ultimate MG** 连接,连接完成后 **状态指示灯** 常亮。

#### **Turbo Function**

- Home button, LSB/RSB, and P1/P2 buttons are not supported.
- The turbo settings will not be saved permanently and will revert to default settings after the controller is



# P1/P2 Buttons Configuration

- One button on the controller can be remapped to the P1 / P2 buttons.
- Configuration on the LSB/RSB are not supported.
   The Profile LED will blink continuously when the configured button is pressed.



# **Fast Button Swap**

- The Profile LED will blink continuously when the swapped button is pressed, and indicate the function of
- this button has been changed.

   D-pad, Home button, LSB/RSB, + start, select, and P1/P2 buttons are not supported for the
- Press and hold the two buttons that need to be configured, then press the Star button to activate the
  Fast Button Swap. Repeat the same procedure or reconnect the controller will deactivate the function.




#### 连发功能

\* Home 键、左 / 右摇杆、P1、P2 键 不支持连发。 \* 连发功能不会保存,关机或断开连接后恢复默认。



## 配置 P1 / P2 键

- 可将手柄上的单个按键复制到 **P1 / P2 键。** 左 / 右摇杆 不支持配置。 已配置的按键使用时 配置指示灯 会持续闪烁。



# 快速交换按键

- 已交换的按键按下时 配置指示灯 会持续闪烁表示此按键的功能已变更。
- 方向键,左广扫腾柱。 方向键,左广扫腾杆、减号键,加号键、Home键,P1,P2键,不支持交换。 按住需要交换的两个按键,再按下星号键完成交换。重复此操作或重新连接手柄可取消此功能。



# **Battery**

Low battery mode

Battery charging Battery fully charged

Red LED blinks Green LED blinks

- $Built-in 300 mAh \ rechargeable \ battery \ pack \ with 13 \ hours \ of \ play \ time, \ with \ a \ charging \ time \ of \ 90 \ minutes \ pack \ with \ 13 \ hours \ of \ play \ time, \ with \ a \ charging \ time \ of \ 90 \ minutes \ pack \ pack$
- The controller will automatically shut down if it fails to connect within 1 minute of startup, or if there are no
- operations within 15 minutes after establishing a connection. The controller will not shut down during wired connection.

# **Safety Warnings**

- Please always use batteries, chargers, and accessories provided by the manufacturer.
   The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved
- $\bullet \ \, \text{Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in } \\$
- · Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions
- Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

# 电源

电源状态 电源指示灯状态 电量不足 红灯闪烁 正在充电 绿灯熄灭 充电完成

- 配备 300mAh 可充电式锂电池,可持续使用约 13 小时,充电时间约 90 分钟。 开机后1分钟内未连接,或连接后15分钟无操作会自动关机。
- 使用有线连接时不会自动关机。

## 安全警示

- 请使用制造商的电池、充电器、配件。
- 在用户使用第三方的配件时,制造商不能对用户的安全负责。
- 请勿自行拆卸、改装或修理设备。 请勿挤压、拆解、刺穿或尝试改装设备及电池。
- \* 对设备的任意变动或改装,将导致制造商对设备不予保修。

## **Ultimate Software**

 $Please\ visit\ app. 8 bit do. com\ to\ download\ the\ \textbf{Ultimate}\ \textbf{Software}\ to\ get\ the\ latest\ firmware\ \&\ additional\ support.$ 

## 自定义配置

请访问 app.8bitdo.cn 获取 精英软件 使用。

# Support



· Please visit support.8bitdo.com for further information & additional support.







\* 请访问 support.8bitdo.cn 了解详细信息。

