





Please refer to the following
for more details



User Guide

OPENMOVE S691


ON/OFF



Turn on the headphones
Press and hold the Power/Volume+ Button for 2 seconds until the LED Indicator flashes blue.


Turn off the headphones
Press and hold the Power/Volume+ Button for 3 seconds until the LED Indicator flashes red.

Pairing ①




1. Start with OpenMove turned **off**.
2. Press and **hold** the **Volume+** Button for **5 seconds** or until the LED Indicator **flashes red and blue**.

Pairing ②



3. Open your device's **Bluetooth** settings and select "**OpenMove by Shokz**." Audrey will say "connected."

Multifunction Button



- ▶|| Play/pause music ● Click once
- ⏮ Next song ●● Double-click while music is playing
- ⏭ Previous song ●●● Triple-click while music is playing
- ☎ Answer call ● Click once
- 📞 End call ● Click once

Volume - Button

Volume - knop

Diagram illustrating the Multifunction Button on the Shokz headset. The button is located on the side of the earpiece and is used to control various functions, including play/pause, stop, previous, next, volume up, volume down, and a call function.

[illegible]