



Original	Recharge
	Power
	CD
	Open/Close
	USB
	Source
	FM/DAB+
	PRG/Memory
	Menu/Repeat
	<</I<<
	Play
	Pause
	>>/>>I
	Fold-
	Fold+
	Info/Random
	10-/Tun-
	10+/Tun+

Original	Recharge
	Stop/Auto
	Vol-
	Vol+
	EQ/Clock
	Mute/Sleep
	Stop / Hold
	Vol-
	Vol+
	Subtitle / EQ
	Mute / Dimmer

