


Power supply mode	Type-C
Voltage	5V
Input current	1A
Wireless mode	Infrared, Wi-Fi
Operating frequency	2.4GHz
Infrared range	10m
Wi-Fi range	Indoor 5m / Outdoor 90m
Installation	Wall mounting / Desktop
Operating temp	-20 ~ +40 °C
Operating humidity	≤ 85%RH
Dimensions	68x28mm
Execution standard	AS4268
Warranty	2 Years



emerald.com.au



Download


Download Emerald App

and follow the in-app steps to connect your device.




Position

Position within 10m of your air con in **clear line of sight**, on a table or wall using the supplied fittings, and plug in.



Unobstructed signal



Obstructed signal

Discover

Automatically switches your air con off when the last person leaves, or turns on during off-peak times to **save on bills**.



emerald.com.au/aclink

Support

Need more help?

Scan for user guides, video tutorials and customer support.



emerald.com.au/support