


单页尺寸: 75*130mm 108g 铜版纸 折页 双面黑白印刷

Lemon miniUser Manual



Connection Diagram





Installation Steps

- 1. Connect the TV Box with the power supply
- 2. Connect the TV Box to your TV with HDMI cable or AV cable
- 3. Connect the TV Box to internet For wired connection, plug in Ethernet cable from TV Box to your modem or router For wireless, choose the WIFI network and input the WIFI password later
- 4. Set up TV Box on start wizard program step by step
- 5. Enjoy your 4K HDR content

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received,
- including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Made in china

