

HOW TO: REFILL AIR PRESSURE TANK

If you begin to notice a drop in the performance of your RIDGID 18V Brushless Framing Nailer, you may need to refill the air pressure tank. This is a simple maintenance task most tool-owners can do themselves.

TO WATCH A STEP-BY-STEP VIDEO ON HOW TO REFILL YOUR RIDGID 18V BRUSHLESS FRAMING NAILER AIR PRESSURE TANK

CLICK THE PLAY BUTTON BELOW



COPY AND PASTE THIS LINK https://www.youtube.com/watch?v=97CUxqNrzws

RELEVANT NAILERS





TOOLS NEEDED

- Air Compressor
- Air Hose
- 1/4 in. Ball Chuck Fitting
- 4mm Hex Key
 Included with and stored on your Framing Nailer



HOW TO: CLEAR A NAIL JAM

Although unlikely, you may experience a nail jam while using your RIDGID 18V Brushless Framing Nailer. The nail jam indicator, located at the base of the tool, will alert you by flashing red. Nail jams are simple to remove in a few quick steps.

TO WATCH THIS STEP-BY-STEP VIDEO ON HOW TO CLEAR A NAIL JAM IN YOUR RIDGID 18V BRUSHLESS FRAMING NAILER

CLICK THE PLAY BUTTON BELOW



COPY AND PASTE THIS LINK https://www.youtube.com/watch?v=uv5LZCDN4Bw

RELEVANT NAILERS



TOOLS NEEDED

4mm Hex Key
Included with and stored on your Framing Nailer



HOW TO: INSTALL EXTENDED CAPACITY MAGAZINE

Double the nail capacity of your RIDGID 18V Brushless Framing Nailer by installing a RIDGID Extended Capacity Magazine. Get jobs done faster and more efficiently by reducing the number of nail reloads. Installation involves just a few simple steps.

TO WATCH THIS STEP-BY-STEP VIDEO ON HOW TO INSTALL AN EXTENDED CAPACITY MAGAZINE ON YOUR RIDGID 18V BRUSHLESS FRAMING NAILER

CLICK THE PLAY BUTTON BELOW



COPY AND PASTE THIS LINK https://www.youtube.com/watch?v=A5WUfjkUccl

RELEVANT NAILERS



TOOLS NEEDED

4mm Hex Key
Included with and stored on your Framing Nailer