




## PRODUCT STRUCTURE



## BATTERY INSTALLATION




## PAIRING SETTING




## INSTRUCTIONS

### Remote control operation method



## INSTRUCTIONS

### The socket function key operation method



## PRODUCT SPECIFICATION

