




Original	Replacement
	 Power
	 List
	 TV/R
	 Shift + Pre Ch
	 Sleep
	 AV
	 Shift + Dual
	 Shift + Format
	 Eject
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8

Original	Replacement
	 9
	 0
	 Info
	 Pre Ch
	 Pause
	 Guide
	 Dual
	 Mute
	 Vol +
	 Vol -
	 Ch +
	 Ch -
	 Ok
	 Up
	 Down
	 Right
	 Left



