

Permanent Analyses of Renewable Hydrogen with Sensors

# **User Guide**

# **TABLE OF CONTENTS**

1.	OBJECTIVE	2
2.	SYSTEM COMPONENTS	3
3.	INSTALLATION INSTRUCTIONS	4
4.	PROBLEMS AND SOLUTIONS DURING INSTALLATION	7
5.	PRODUCT SPECIFICATION SHEET	8
6.	GENERAL INFORMATION – CERTIFICATION	9

# Hazard warnings and safety symbols

<u> </u>	Information in this manual that may affect the safety of users.  If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired
L	Important/useful information and instructions are shown clearly throughout the manual in a note format.

# 1. OBJECTIVE

Hydrogen is a key component of the energy transition movement and natural hydrogen could be part of it. Indeed, emanations coming out of the ground have been detected in several places in the world.

However, this molecular hydrogen is extremely diffuse and requires dedicated instrumentation to be detected.


PARHyS instrument is designed to remotely and continuously monitor natural hydrogen emanations in the soil at

a depth up to 1 meter. This measurement may be realized at regular interval (1h to 24h).

PARHyS use LoRaWan network (public or private) and Bluetooth communications.

PARHyS also allows the recovery of gas from the ground via a balloon that can be placed at the vent. The various components of the gas other than hydrogen can thus be measured by gas chromatography.

# 2. SYSTEM COMPONENTS



# 3. INSTALLATION INSTRUCTIONS


### Parts included in the package

- PARHyS sensor packed.
- Inox sampling tubing not plugged.
- User Guide.

# Tools box (not included in the package)

- 2 Thionyl Chloride 3.6 V Size D.
- Screwdriver Philips medium to remove/install the top of the globe.
- Portable perforator.
- Drill φ12x1000 mm.
- Smartphone Android 10+.
- Smartphone Apps,
- Option: Gas sampling flask or bag with a minimum volume of 0.5 l.

### First preparation before installation



• Remove the 6 screws on the bottom 1 to remove the top of the globe 2.

- Place the 2 batteries type 3.6V-19Ah Thionyl Chloride respecting the polarities 3.
- Replace the top of the globe.
- Switch the PARHyS sensor by pushing the On/Off button:
  - 2 LED flashing consecutively.
  - When PARHyS sensor is started (around xx seconds) : rapid flashing of the power button LED.
- Start Apps Nanotech on your Smartphone (refer to Nanotech Apps documentation load on www.website. Crigen.com).
- Pair PARHyS sensor by pressing the Bluetooth button.
  - BLE connectable: slow flashing of the BLE button LED.
  - o BLE connected: rapid flashing of the BLE button LED.
- If PARHyS Sensor is connected to the Gateway, the 2 LED simultaneous status are :
  - Transmission of the join request: 1 flash.
  - o Failure of the join procedure: 2 flashes
  - o Reception of the join successful: 4 flashes.
  - First frame received: 6 flashes.
- Plug the sampling inox tubing with the globe ④. A mark on the sampling inox tubing indicates the ideal
  pushing length.



The two O-rings must not be removed from their location. They are shown to indicate that providing the gas tight seal their presence should be checked.

### Installing PARHyS sensor into the soil



Check on your smartphone that the module has been paired.

- A hole about 1000 mm depth and 12 mm in diameter is drilled in the ground with a portable perforator.
- Insert sampling tubing into the hole to a depth of 1000 mm (or less).



Ensure the path gas tube is not crushed, around 20 cm up to the soil.

Measurement procedure (refer to Smartphone Apps User Guide)

- Start the Manual measurement mode in the Smartphone Apps: data retrieved as a csv file on the Smartphone directly.
- Start the Automatic measurement mode in the Smartphone Apps: data retrieved every hour from a server.



I could be necessary to Push Bluetooth button again since for energy saving the BLE switches off.

## Balloon/bag installation procedure

PARHyS makes it possible to collect a punctual sample of gas from the soil for chromatographic analysis with a balloon.

- Push Bluetooth button at the bottom of globe.
- Start up the Smartphone Apps Nanotech.
- Stop the automatic data transmission if in progress via the Apps.
- · Place the balloon/bag at the vent either by :
  - o Inserting a latex balloon directly onto the air vent silencer.
  - Unscrewing the air silencer and screwing a balloon/bag with a M5x0.8 male connector directly to the vent filter.
- Start the Balloon mode in the Apps.
- Remove the balloon/bag after collecting the gas.

# 4. PROBLEMS AND SOLUTIONS DURING INSTALLATION

# Good practices for transport and storage

- Drive to the site with PARHyS sensor inside the vehicle, not in the trunk, where it could be subjected to extreme temperatures and possible shocks.
- Do not place PARHyS sensor against a hot object (e.g. in a car left in the sun during the summer).
- Protect PARHyS sensor from direct sunlight and heavy rain when installing to avoid temperature rising in PARHyS's measurement chamber which may result in erroneous readings.

Problems encountered	Solutions
After pushing the On/Off button PARHyS sensor does not activate.	Check that the batteries are properly installed in the battery compartment and/or their status.
	Check that the On/Off button is not damaged.
Sampling inox tube is not properly inserted.	Check that the O-Rings and/or the mark on the sampling tubing are correctly positioned.
Pairing between PARHyS sensor and the Smartphone Apps fails.	Check that the smartphone is in Bluetooth mode.  Press the BLE button under the globe.
Pairing between Parhys and the Gateway fails.	Switch off Parhys sensor by pressing the On/Off button and repeat the procedure <b>Before installation</b> (§3).

For further problems contact CRIGEN-NSWLab@engie.com

# 5. PRODUCT SPECIFICATION SHEET

-	J. PRODUCT	SPECII ICATIO	IN SITE			
_	Description	Values	Units	Remarks		
General	Supply Voltage	3.6	V			
	Range	1 000	meter	Between PA	Between PARHyS and LoRaWan gateway - free space	
	Operating Temperature	-5 to + 50	°C			
	Storage Temperature	-10 to +75	°C			
	Operating Humidity	10 to 95	%			
	Storage Humidity	5 to 95	%	Best storage environment 0-20°C, 50%HR wo condensing		
	Battery type	Thionyl Chloride 3.6 V		2 x Type D (SL-2780)		
	Battery capacity	19	Ah			
	Battery replaceable	Yes				
	Battery time life	1	year	PARHyS –1 sample every 4 hour - 1 transmission by sample		
	Upload interval range	1 to 24	hours	LoraWan configurable 1 to 24 time/day		
	Sample interval range	1 to 24	hours	Configurable	e by customer or smart	tphone Apps
	Warranty	1	year	- J	,	
	H <sub>2</sub> concentration	0 to 1 000	ppm			
are	Accuracy	< ± 10	%	Temperatur	e between 22 and 39°0	
Measure	Temperature	-5 to + 50	°C			
-	Humidity	10 to 95	%			
	Communication	LoraWan , BLE				
	Protocol	LORA EU	LORA US	I	LORA AU	Bluetooth BLE
tion	Frequency	863-870MHz	902-928M	H <sub>7</sub>	915-928MHz	2402-2480MHz
unica	Receive sensibility	-137dBm	-132dBm	112	-137dBm	-90dBm à 1 Mbps
Communication	RF output power	+14dBm max, 25mW		nax, 63mW	+18dBm max, 63mW	+4dBm max, 2.5mW
8	Antenna gain: peak gain	-3.2dBi	-3.0dBi	-3.0dBi		
	Antenna Type	Omni directional	dBi		•	<u> </u>
u o	General	CE				
Certification	Communication	FCC, IC, RED				
Grti	Equipment	ROHS		Cat 9		
F	Globe height					
	Globe diameter	154	mm			
	Globe material	ABS-PMMA				
<u> </u>	Globe color	White glossy				
Mechanical	Sample tubing height	1100	mm			
Ř	Sample tubing diameter	10.5	mm			
	Sample tubing material	Inox 316L				
	Connection tubing-globe			Two O-rings ensure the seal		
	Weight	1051.2	g	Without battery.		
Addendum	Smartphone Apps	Android 8.1+		Standalone measurements with csv data. Receiving flash local memory (up to 8000 samples). Configuration.		
	LEGEND communication	Contact us		Private LoRaWan gateway with Iridium satellite communication and energy harversting. LEGEND gateway: 100 PARHyS over 1 km distance. This solution is recommended out off Lora network.		
Ac	Public LoRaWan	Orange business LoRaWan Bouygues Objenious Other network contact us		Native language of public operators.		

# 6. GENERAL INFORMATION – CERTIFICATION

### General product information



Separate collection, handling and disposal for waste electrical and electronic equipment and its components.



#### Calibration gases

The sensors are delivered with a calibration information.

It is however possible to check the calibration with a standard H2 gas injected at 25°C and 50%RH.

#### Service

PARHyS should be regularly serviced by ENGIE to ensure correct and accurate operation.

At the end of the life, request RMA (Return Material Authorization) before returned to ENGIE for WEEE procedures.

#### Warranty policy

This instrument is guaranteed, to the original end user purchaser, against defect in materials and workmanship for a period of 2 years from the date of the shipment to the user. During this period ENGIE will repair or replace defective parts on an exchange basis. The decision to repair or replace will be determined by ENGIE.

#### RF information

Changes or modifications not expressly approved by ENGIE could void the user's authority to operate the equipment.

#### FCC Part 15 compliance statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### License-Exempt Radio Apparatus (ISED)

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

#### Appareils radio exempts de licence (ISDE)

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1. L'appareil ne doit pas produire de brouillage;
- 2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### Radio Frequency (RF) Exposure Compliance of Radiocommunication for mobile Apparatus

To satisfy FCC and IC RF Exposure requirements for mobile devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this distance is not recommended. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### Conformité à l'exposition aux champs RF des équipements radio mobiles

Pour satisfaire aux exigences FCC et IC concernant l'exposition aux champs RF pour les appareils mobile, une distance de séparation de 20 cm ou plus doit être maintenu entre l'antenne de ce dispositif et les personnes pendant le fonctionnement. Pour assurer la conformité, il est déconseillé d'utiliser cet équipement à une distance inférieure. Cet émetteur ne doit pas être co-situé ou fonctionner conjointement avec une autre antenne ou un autre émetteur.

### UE Declaration of Conformity

Document Number: M CRISEN NAN 2022 0088

We, the undersigned,

Manufacturer or representative: ENGE SA

Address: 1 Place Service Champion, 80400 CCOURSEVOIE

COUNTY FRANCE

Phone number: +33 149 225 000 E-mail: ORIGINENSWiseigenger.com

Designated product,

Descriptions

Brand name or trade mark: UNG/E

Startification / Designation: PAPINyS Service

Restrictive use: None

Frequency tuesd for BLR

Max power: Frequency transition LORA: 2400-2483 5MHz 10mW w.i.r.p 863-670MHz

Man priver:

25mWesp

Certify and declare under our sale responsibility that the designated product is in conformity with the assential requirements and provisions of the following European Directives:

III Directive 2014/53/EU of the European Parkement and at the Council of 16 April 2014 on the harmonization of the twey of the Member States, receing to the making available on the market of radio equipment (RED). The conformity of the designated product(s) with the provisions of this European Directive is given by the compliance.

Ensertial requirements of article 3.1() of RED	EN 61010-1 (2010+A1/2019)
(Surery, electrical) Essential requirements of article 3.1(a) of RECI (Safety, bealth)	EN 82311 (2020)
Covertol requirements of article 3.1th of RED: (Executiving retro Compatibility)	EN 81326-1 (2021) ETS: 301 489-1 (V2.2.3) ETB: 301 489-3 (V2.1.1) ETB: 301 489-3 (V2.1.1)
Ensential requirements of article 3.2) of RED. (Efficient use of radio spectrum)	ETS: EN 300 326 (V2.2.2) ETS: EN 300 220-1 (V2.1.1) ETS: EN 300 220-2 (V3.1.1)

St Directive 2011/98/8U of the Dungeon Parliament and of the Council of 8 June 2011 on the restriction of the Law of contain hazardous substances (ROHS) in electrical and electronic equipment.

S) Directive 2012/19/EU of the European Parliament and of the Council of 4 July 2012 on winds-electrical and westronic equipment (WESE).

Name and position of person binding the manufacturer or his authorized representative

Name: DUTERQUE Adeline

Position: Head of ENGIE Lab CRIGEN

Address: 4 Rue Josephine BAKER, 93240 Stains - FRANCE

Email. CRIGEN-NSWIab@engie.com

Signature

CHECKLES CONTROL (The Dissiples Date: (2010) 27AMG (France) (1) 102.03 5 46.27 ID 00