

3. To connect the headphones to a PC or old version Laptop for use with VOIP applications, such as Skype or chat programs, MSN Messenger, Yahoo, Google Voice etc. You will need a 3.5mm Mic Audio Y Splitter Cable (purchase separately).

3.3 Basic Operation of the in-line MIC (MFB button) on Smart Phones

Button	Function	Operation
 MFB (Multi-function Button)	Answer a call/End a call	Press MFB once
	Reject a call	Press and hold MFB for 3 seconds
	Play/Pause media	Press MFB once
	Next track	Double-press MFB
	Previous track	Triple-press MFB
	Activate voice recognition apps on your mobile device	Pressing MFB button for more than 3 seconds will activate voice command (e.g., Siri) when connected to an Android or an Apple device

Note:

- * Not all devices support this in-line remote control functionality.
- * You may need to open the media player application for initial play back to start.
- * If there is a phone call while you are listening to an audio, the phone call will take precedence over the audio, and after the call, it will automatically return to the previous listening state.

Limited Warranty

12 months limited warranty: Simolio provides full warranty due to defects in materials and workmanship for a period of 12 months from the original date of purchase. The warranty period is not extended if we repair or replace warranted product.

This warranty is provided at the discretion of Simolio Ltd. And does not cover appearance damage or damage due to acts of nature, accident, misuse, abuse, negligence, commercial use, or modification of or to any part of the product. Accessories such as extended cable, RCA convert cable and perishable items such as earmuffs are not covered under this warranty.

Technical Specifications

Left-Right Channel Separation	70dB
Distortion	≤0.5%
Signal-to-noise ratio	≥80 dB
Power supply	Built-in 500mAh Li-ion Battery
Charging way	USB Type-C Charging Cable
Working time	40 hours
Charging time	3 hours

If you have any questions, please feel free to contact us via:

support@simolio.com (NA/AU)
support_uk@simolio.com (UK)



Voice Enhanced TV Headphones SM-905 TV User Manual

Thank you for choosing SIMOLIO SM-905 TV, which is specifically designed for you to enjoy TV or music or other content in a convenient way with great sound experience and don't worry to disturb your family. Please read this guide carefully so you can take full advantage of SIMOLIO and keep it in a safe place for future reference. We hope that you're very happy with your SIMOLIO, if you have any questions, please feel free to contact us via:

support@simolio.com (NA/AU)

support_uk@simolio.com (UK)

Response Time: 2-24h, excl. holidays




Using Your Headphones

1.1 Turn on the Headphones

Slide ON/OFF switch to "ON" position.

Note:

1. Please charge the headphones for 3 hours before using it for the first time.
2. It CANNOT be used as normal wired headphones without battery as these are battery-operated headphones with Tone Control function.



1.2 LED Indication


LED Status	Headphone Status
Green LED lighting steadily (LED 1)	Working
Red LED flashes (LED 2)	Low power indication
Red LED on (LED 2)	Charging
Red LED off (LED 2)	Charging completed

1.3 Charge the Headphones

You can charge your headphones by plugging the USB Type-C power cable into a phone charger (5V/500mA-2Aoutput), PC USB port, TV USB port or any other USB outlet.


Note:

The charging time is approx. 3 hours. The headphones will last around 40 hours on a full charge, but will last a lesser or greater amount of time depending on the average volume level of the headphones. (It is recommended to turn off the headphone after using it.)



1.4 TONE Control

You can adjust the tone by rotating the TONE control dial (under the decorative cover on the right side of the headphones) clockwise as needed so you can hear the TV clearly. Note: up to 12dB adjustment.




Kindly reminder:


Please make sure the headphones are being worn properly.

A. Each side of the headphone has a letter to guide the wearer: "L" for left and "R" for right. You can adjust the retractable headband to fit you better.

B. It's a 90-degree rotation design that can't be folded up. If you experience resistance while rotating, please check and change to the correct rotation direction.




You can only rotate it 90 degrees in a specific direction as above.




Using the Headphones with TV

2.1 AUX/3.5mm Audio Out



2.2 RCA Audio Out (must be labeled AUDIO OUT)




Note:


- * For TVs with only Optical and/or Coaxial audio output, you will need to purchase a Digital to Analog Audio Converter (DAC is available at our store separately) for installation.
- * For AV receivers with a 6.35mm phone jack at the front, you will need to purchase a 6.35mm to 3.5mm audio adapter for installation.

Using the Headphones with PC / Tablet / Phone

3.1 Using the Headphones to Listen to Music



3.2 Using the Headphones to Make a Call or Chat on-line.



Note:

1. When using the 1.5M audio cable, please make sure the plug with 4 pole (ref. Fig 1) is inserted to the audio device like PC, tablet, phone. Otherwise the MIC will not work.
2. MFB function is only available in smart phones.