



# Mcombo

---

ACCENT CHAIR

with OTTOMAN

6151-4055/4058/4059



**Toll Free(US) :** 3235971109

**Website :** [www.mcombo.com](http://www.mcombo.com) Amazon sold by: MCombo

**Warranty Claim :** [sales@mcombo.com](mailto:sales@mcombo.com)

**Sales & Technical Questions :** [sales@mcombo.com](mailto:sales@mcombo.com) [sales@exacme.com](mailto:sales@exacme.com)

# CONGRATULATIONS!

Mcombo Accent Chair with ottoman - a name synonymous with classic design and the carrier of value and quality. Our products are directly from factory and eliminated the cost of middlemen. The Accent Chair with ottoman is a high-quality shading solution to enhance comfortable feelings as you try to enjoy the nice day.

## WARRANTY


- All warranties are to the original purchaser from **MCOMBO ONLY**®
- **MCOMBO**® will replace the defective parts or send replacement item provided that the warranty parts have not been subjected to misuse, abuse or improper service by the consumer, for example, damaged wire arising in consequence of negligence or improper operation.
- **MCOMBO**® All of chairs come with a 30-day return/replace policy. During this time, we will cover the shipping cost of return and replacement for defective and damaged item, through provide pre-paid return label or pick up service for customer's convenience.

### PARTS LIST

### NOTE


Part #G is in part #A / Parts #C, #D, #E, #M, #Screw Pack( #I, #J, #K, #N, ) are in Part #B, and the screw pack is tied to part #E. / Unzip the #A, #B zippers, take out the above parts and start the assemble.

A




A\*1 Ottoman Pad

B




B\*1 Chair & Seat Pad

C




C\*3 Crossbar

D




D\*1 Chair Crossbar (Back)

E



E\*2 Ottoman Legs

F



F\*2 Chair Legs

G




G\*1 Ottoman Cushion

H




H\*1 Chair Cushion

I




I\*8 Screw M6\*16mm

J




J\*6 Screw M6\*30mm

K




K\*8 Screw M6\*50mm

L




L\*1 Back Cushion

M




M\*2 Wooden Armrest

N



N\*1 Wrench


O



O\*1 Lumbar Pillow

Please remove all protective foam.

## Assemble the Ottoman





### Step 1

Fix 2 Crossbar **#C** and 2 Ottoman Legs **#E** with Screw **#I**.

### Step 2

Use Screw **#K** to fix the frame of the ottoman installed in the previous step on the Ottoman Pad **#A**.



### Step 3


1. Peel off the non-woven fabric from the Velcro strip of Ottoman Cushion **#G**.
2. Place Ottoman Cushion **#G** on Ottoman Pad **#A**, and the ottoman assembly is complete.

## Assemble the Chair

### Step 4



Use 1 Crossbar **#C** and 1 Chair Crossbar (Back) **#D** to fix 2 Chair Legs **#F** with Screw **#I**.

**Please Note:** It is necessary to distinguish the front and rear directions of the chair legs. The front side is connected to Crossbar **#C**, and the rear side is connected to Chair Crossbar (Back) **#D**.



## Step 5

1. Secure Seat Pad **#B** and front side of Chair Legs **#F** with Screws **#K**.
2. Secure the attached Chair Crossbar (Back) **#D** to Seat Pad **#B** with Screws **#J**.




## Step 6

1. Place Chair Seat Cushion **#H**, Chair Back Cushion **#L** and Lumbar Pillow **#O** on the Seat & Back Pad **#B**.
2. Fix the Wooden Armrest **#M** to the Chair Legs **#F** with Screw **#J**, with the wide side facing the front of the chair.

## Congratulations!



Now you can relax your body on this chair and even decorate your living room.






## 1. Adjust the Chair Backrest Backwards

1. Unzip the zipper on the backside of the backrest and pull out the legs inside the backrest.




2. Press the back of the chair forward and then back down.




## 2. Adjust the Backrest to the Sitting Position

**Note:** need to retract the legs on the back of the chair first



1. There is a round button on the side of the base of the backrest leg.  
First lift the chair leg up slightly, press the button, and then retract the backrest leg.



2. After the backrest is completely flattened, you will hear a click and you can adjust the backrest angle back.

3. When adjusting the angle back, a total of two clicks will be heard, which means that both angles can be fixed.

