




Installation & Assembly




Components List



Carton 1



H X1



I X1




J X2




K X2


Carton 2




L X1



M-L X1



N X2



O X1



K X1




S X1


Hardware List

A	B	C	D	E
				
X4	X1	X8	X4	X2


Components List




Carton 3




P X1




M-R X1



Q X1





R X1




N X1

STEP 1


	Ax2
	Bx1
	Cx2
	Dx4
	Ex2



STEP 2




STEP 3




STEP 4


	Ax2
	Bx1
	Cx6
	Ex2




STEP 5




STEP 6




STEP 7




STEP 8



STEP 9



STEP 10



STEP 11

