


148x210mm

148x210mm


# AIRYOMI

User Manual

K9



Product description



Product specification

Model no.	K9		
Rated voltage	125V	Motor	11,000RPM brushless digital motor
Rated frequency	50Hz	Rate Power	2000W

Product function

1. Dry hair quickly in 1.3 minutes:  
Derived from the core power-110,000 rpm high-speed brushless digital motor, with 29mm diameter and 70g weight only; The rotation speed is 5-6 times that of an ordinary motor, provides hurricane-level power when blowing, greatly improving the efficiency of dry hair;
2. Airflow multiplication technology:


- High-speed air guide channel design, driven by a 110,000 rpm high-speed brushless digital motor, 11 aluminum metal wind wheels rotate rapidly, advancing a wind speed of about 24 meters per second, squeezing the peripheral air toward the middle to achieve airflow double;
3. The sound is meticulously modulated to reduce sharp noises and make your hair dry:  
Optimize the motor and air duct, professional sound adjustment, effectively reduce the vibration generated by the airflow, control the noise within the range of auditory acceptance, and bring a more pleasant dry hair experience;
  4. Intelligent constant temperature technology:  
The use of intelligent thermal sensors and intelligent temperature control monitoring prevent excessive temperature damage to the hair and protect the shiny hair;
  5. Choice of 9 blowing modes:  
Cold and warm, high, medium and low speed circulation, meet different hair quality needs, protect scalp and hair;
  6. Negative ion hair care, smoothing frizz and smoother:  
Generate high concentration of negative ions during work to reach the surface of the hairline, neutralize the positive charge on the surface of the hairline, thus smoothing the messy hair, making it more smooth and easy to comb;
  7. A variety of security protections, just for your peace of mind:  
Equipped with overheating, fusing temperature sensor and built-in microprocessor, respectively provide comprehensive safety protection for temperature, voltage, and current, and use it more at ease;
  8. Selection of cleaning mode, automatic cleaning after inlet air net:  
In the shutdown state, press and hold the cold air button for 3 seconds, turn on the power switch, the motor reverses to enter the cleaning mode, and it will automatically shut down after cleaning for 10 seconds;
  9. Equipped with modeling windshield to create a perfect shape.

Operation instruction


1. Make sure if voltage in your home is same as product rated voltage or not before using. Also make sure this product is off ("0" is off and "1" is on).
2. Insert the power plug into the socket, turn on the power button, and switch the power button to the "1" position.
3. The setting of this product when turning on is medium speed and medium temperature.
4. Wind speed setting button: lightly press the wind speed button to adjust the wind speed; in the current mode, the wind speed changes in three gears.
5. Temperature setting button: lightly press the temperature setting button to adjust the temperature; the blue indicator light is the cold air, the orange indicator light is the warm air file, the red indicator light is the hot air. And the setting of this product when turning on is medium temperature.
6. Cool / hot wind setting button: Press this switch lightly to switch between cold and hot air.
7. Cleaning mode: In off status, press and hold the cold / hot wind setting button for 3s, turn on the power button, the motor reverses to enter the cleaning mode, and it will automatically shut down after cleaning for 10s.

8. After use, turn off the power button to "0" position and unplug the power plug.

## Installation and disassembly



Installation method: This product is equipped with two nozzles and one diffuser. Please select the nozzle you want to use. Align the bottom of the air nozzle with the air outlet and lightly buckle. When you hear a "click", the nozzle is fixed.




Disassembly method: Take down the nozzle from the hair dryer and remove the nozzle.

Note: Please install and remove the nozzle in the off status. Do not adjust, load and unload the nozzle during use. When disassembling the nozzle after use, wait for the nozzle to cool before removing it to avoid burns.

## Cleaning and maintenance


- Do not use paint thinner, benzene, alcohol, etc. to clean this product, so as to avoid malfunction, cracking and discoloration of this product
- The hair dryer is equipped with a micro filter, which can prevent very small particles (hair, hair spray, dust) from entering the body and prolong the service life.
- In order to achieve the best results, it is strongly recommended to activate the automatic cleaning system to clean once every working day. In addition, in order to ensure the best performance of the hair dryer, it is recommended to manually clean the filter with a brush every 7 days.



When cleaning the air outlet, please make sure that the product is not plugged into the power plug. Please remove the air nozzle, use a cotton swab to remove the attachments on the air outlet, and wipe the product with a dry cloth.

### ONE STEP AUTOMATIC CLEAN FUNCTION

Hold the cool shot button when power off and turn on the hairdryer, the motor reverse to clean the back cover for 10s



When cleaning the air inlet, please make sure that the product is not plug, use a cotton swab or teeth brush to remove the attachments on the air inlet.

## Important safety instructions

When using electrical appliance, especially when children are present, basic safety precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS BEFORE USING.**

**KEEP AWAY FROM WATER. DANGER:**

As with most electrical appliances, electrical parts are electrically live even when the switch is off.

**To reduce the risk of death by electric shock:**

1. Always "unplug it" immediately after using.
2. **DO NOT** use while bathing.
3. **DO NOT** place or store this appliance where it can fall or be pulled into a tub or sink.
4. **DO NOT** place in or drop into water or other liquid.
5. If an appliance falls into water, "unplug it" immediately. **DO NOT** reach into the water.

**WARNING: To reduce the risk of burns, electrocution, fire or injury to persons:**

1. An appliance should never be left unattended when plugged in.
2. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. **DO NOT** use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped into water.
5. Keep the cord away from heater surfaces.  
**DO NOT** wrap the cord around the appliance.
6. Never use while sleeping.
7. Never drop or insert any object into any opening.
8. **DO NOT** use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
9. Never block the air openings of the appliance or place it on a 50ft surface, such as a bed or couch, where the air opening may be blocked. Keep the air openings free of lint, and the like.
10. **DO NOT** direct hot air toward eyes or other heat sensitive areas.
11. Attachments (when furnished) may be hot during use. Allow them to cool before handling.
12. **DO NOT** place appliance on any surface while it is operating.
13. While using the appliance, keep your hair away from the air inlets.
14. **DO NOT** operate with a voltage converter.
15. **DO NOT** uses an extension cord with this appliance.

### SAVE THESE INSTRUCTIONS USER MAINTENANCE INSTRUCTIONS

This appliance is equipped with a thermostat that may cycle OFF if the temperature exceeds comfort level due to partially blocked air inlet or air outlet openings. In the event that the appliance stops during use, turn off the switched and allow the appliance to cool down, at which time the thermostat will automatically reset. During use, **DO NOT** block the air openings. When using this appliance near water (e.g., bathrooms), the use of an Electrical outlet protected by a Ground Fault Circuit Interrupter is recommended.

### MAINTENANCE

Your appliance is virtually maintenance free. No lubrication is needed. Keep heated surface clean

and free of dust, dirt, and hair spray. If cleaning becomes necessary, disconnect the appliance from the power source and wipe the exterior with a damp cloth. If the cord becomes twisted, untwist prior to use. WARNING: If any malfunction occurs, **DO NOT** attempt to repair it yourself. This appliance has no user-serviceable parts.

**STORAGE when not in use, “unplug it.”**

Allow the appliance to cool and store out of reach of children in a safe, dry location. Never wrap the cord around the appliance since this will cause the cord to wear prematurely and break. Handle cord carefully for longer life and avoid jerking, bending sharply, twisting or straining cord, especially at plug connections.