

TIPS & TRICKS



Attach the floor nozzle to the handheld for a fast and easy way to clean stairs!



Attach accessories to the end of the wand for the versatility to clean up high



Clean and rinse filter regularly to maintain performance
(dry for 24 hours before reinserting)



Blade Microfiber Hard Floor Nozzle for large debris pick up on hard surfaces



Hoover's most powerful cordless vacuum with the high performance digital motor



More runtime with extra batteries. Visit Hoover.com/ONEPWR to purchase additional ONEPWR batteries.

961003496



ONE
PWR™
SYSTEM

CORDLESS

QUICK START GUIDE

BLADE MAX CORDLESS VACUUM



CLEANING AND MAINTENANCE

1



Pinch the lever and pull up to remove the dirt cup.

2



Press to empty dirt and debris.

3




Pull open the lid to access the filter for cleaning.

4



Remove the cyclone for easier cleaning.




5

Replace dirt cup by aligning the stickers and rotating it back onto the pole.

BLADEMAX RUNTIMES

MODE	SUCTION +	BRUSH ROLL ⌚	BOOST ON
3Ah	STANDARD	OFF 33 MINS ON 27 MINS	6 MINS
4Ah	STANDARD	OFF 45 MINS ON 37 MINS	9 MINS

OPERATION



Customize your clean!

ⓘ Press to turn Machine On/Off.

⌚ Press to turn Brush Roll On/Off.

NOTE: We recommend that you turn the Powered Floorhead Brush Roll OFF for hard floors and ON for carpets. Using with the Brush Roll OFF with extend runtime.

+ Boost Mode: Increases the suction power to get a deeper clean.

See user manual for complete instructions



HOOVER® ONEPWR™ Cleaning Products share the same interchangeable battery for an easier, faster, cord-free cleaning routine. Visit [Hoover.com/ONEPWR](https://www.hoover.com/ONEPWR) to discover the full range of ONEPWR cleaning products.



PWR UP.

Add Batteries for More Runtime.

Visit [Hoover.com/ONEPWR](https://www.hoover.com/ONEPWR) to purchase additional ONEPWR batteries.



WELCOMES YOU TO THE

ONE PWR™

S Y S T E M

Transform the way you clean with power, versatility, and cord-free convenience. From carpets to hard floors, patios and more there's a ONEPWR™ product for your every cleaning need.

NOW THAT
YOU'VE GOT THE POWER,
REGISTER YOUR PRODUCT FOR A CHANCE TO WIN.



ONE WINNER WILL BE CHOSEN EACH MONTH TO RECEIVE
A \$1000 GIFT CARD AND A FREE PRODUCT.


Early Access to Our Biggest Sales • Exclusive Offers
Birthday Discounts • Dedicated ONEPWR™ Customer Service
Product Updates and Cleaning Tips

For complete rules please visit: www.hoover.com/onepwrrules

No purchase necessary. 44 total prizes to be won, one prize issued per month, each prize valued at USD \$1,000. Odds of winning will depend on the total number of eligible entries received and the date of entry. Sweepstakes begins May 1, 2019 and will close on January 1, 2022 at 11:59 PM (ET). Limit one entry per person. Valid only in the U.S. (not including U.S. territories) and Canada. Void in Quebec.

EASY MOBILE REGISTRATION

- 1 Take a photo of the camera icon below including the four bulleted circles (●).
- 2 Send it using one of the two options below:



TEXT PHOTO TO
71403

U.S. ONLY message rates may apply.

OR

UPLOAD ONLINE AT
hoover.com/product-registration
hoover.ca/product-registration
TO ACCESS FULL REGISTRATION FORM

Need Help? Visit www.hoover.com/photoregister or text HELP to 71403.

NO CAMERA?

Go to hoover.com/product-registration and follow the steps until complete
hoover.com/product-registration **hoover.ca/product-registration**