

HOW TO TEST



K&H heated beds may **NOT** feel warm to the touch when your pet is not in the bed.

THIS IS NORMAL! Our products are designed to only warm to maximum temperature when your pet is lying in the bed.

TESTING:

Note: Plug in for 1hr before testing

- 1) Place pillow on top of bed
- 2) Wait 20 minutes
- 3) Feel under pillow, it will be warm, not hot

DID YOU KNOW:

K&H products heat to a perfect pet temperature to ensure your pet is safe. Human heating products can easily burn your pet.

