


# RAKKESTAD



Design and Quality  
IKEA of Sweden



English

## WARNING

**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.







NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.






326949




100219

16x




101345

38x




109567

3x




105248

38x




109041

2x




109837

4x




119595

3x




103717

1x




107091

1x




105494

1x




100001

1x




109221

9x




109338

9x




157308

2x




158568

8x







405950

2x




146857


1x







1




# 2




# 3




4




5




# 6




# 7




8




9




10




11




12




13




14




15





16




17









20




21




22





23








25





26





27








[www.IKEA.com/secure-it](http://www.IKEA.com/secure-it)



[www.IKEA.cn/secure-it](http://www.IKEA.cn/secure-it)




# 29

## English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


**A**




Ø 8 mm  
(5/16")




**1**




**2**



**3**




**B**




Ø 8 mm  
(5/16")




**1**




**2**



**3**




**C**




Ø 3 mm  
(1/8")



**1**




**2**




**3**


30




31




# 32




# 33








# 34



# 35





# 37

