

Flying instructions

FLYBAR VHD2.18J


MAXIMUM ALLOWANCE:
12x VHD2.18J

FLYBAR WEIGHT:
34 kg (75 lbs)

MAX. LOAD:
1750 kg (3858 lbs)

HANGING OPTION:

A	for VHD2.18J - B for SAFETY
B	for VHD2.18J - A for SAFETY



Instructions for hanging or locking positions

1. PLACE THE ALLEN KEY IN THE SLOT
 - 2A. TURN RIGHT TO STOP FOR LOCKING POSITION
 - 2B. TURN LEFT TO STOP FOR HANGING POSITION
- (ALL 4 HANGING SLOTS)

LOCKING POSITION
(TURN RIGHT TO STOP)

HANGING POSITION
(TURN LEFT TO STOP)

