

Use and Care Manual

Usage: Choose a healthy, sturdy tree with a branch strong enough to support the weight of the swing and its occupants. Ensure there are no obstacles or hazards in the swinging path. Use the heavy-duty carabiners provided to attach the swing ropes or chains to the D-rings on the straps. Ensure the carabiners are securely closed and locked to prevent accidental detachment.

Avoid Overloading: Ensure that the weight capacity of the straps and swing is not exceeded. Distribute weight evenly and avoid sudden or excessive force during swinging.

Cleaning: If the straps become dirty or soiled, clean them with a mild detergent and water solution. Rinse thoroughly and allow to air dry before storage.

Inspection: Periodically inspect the straps, carabiners and swing components for any signs of wear, damage or degradation. If any part of the tree swing hanging kit shows signs of significant wear or damage, discontinue use immediately and replace the affected components to maintain safety.

Storage: When not in use, store the straps in the provided carrying pouch or a dry, ventilated area away from direct sunlight and moisture.