

Installation Instructions: Skyline Mini Floodlight (10780/10782/10784/10786)

Read these instructions before installation and retain for future reference This equipment should be installed by a competent electrician



Date	Revision
29.11.2023	1

Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.


- BELL will not accept responsibility for any claims arising from a poor installation.
- The light source of this luminaire is not replaceable: when the light source reaches end of life, the whole luminaire must be replaced.
- Always switch off mains supply before installing.
- Operating Temperature -20°C to +40°C
- External use only

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.



Specification:

	10W	20W	30W	50W
POWER	10W	20W	30W	50W
LUMENS	1100lm	2200lm	3300lm	5500lm
SPHENDON (AxBxC)	91x100x28 mm	112x114x28 mm	142x135x28 mm	183x172x28 mm
COLOR TEMPERATURE	4000K			
LIFETIME	20,000 hours			
BEAM ANGLE	100°			



Technical Helpline +44 (0)1924 893380

www.belllighting.co.uk

British Electric Lamps Ltd, Unit A Foxbridge Way
Normanton Ind Est, Normanton, West Yorkshire. WF6 1TN

T: +44 (0)1924 893380 F: +44 (0)1924 894320 E: sales@belllighting.co.uk