


YZZW-V3

FTPLCG-2047 FTPLCG-2048 FTPLCG-2049 FTPLCG-2050





CONTACT US:

If you have any questions about the installation of YITAHOME products, just contact us at +1 (888) 717-8084 from Mon-Fri 8:00 AM-4:30 PM PST / Sat. 8:00 AM-12:00 PM PST or e-mail us at after-sale.cs@hotmail.com


Alternative method to contact us (amazon.com orders only)
1.Log into your Amazon account
2.Go to "Your Orders" and find the purchase
3.Click on "Contact Seller"


20X30 FT PARTY TENT

YITAHOME



YITAHOME








- 1. Must use ground nails, ropes, and expansions screws for whichever ground you install on for stability to avoid devastating injuries for people inside or nearby and property damage caused by a collapsing gazebo.
- 2. Do not use this gazebo in high winds, heavy snow, or inclement weather. It is not designed to withstand strong gusts of wind, heavy snow accumulation, or other inclement weather. Must take precautions when the wind speed exceeds 25Mph, and clear snow when it accumulates more than 2 inches.
- 3. Before use, thoroughly inspect the gazebo to make sure all bolts, nuts, and buckles have been completely tightened and securely fastened.
- 4. Warranty does not cover damages, losses, or injuries resulting from improper installation, misuse, not using stability accessories mentioned above, non snow cleaning, failure to take precautionary measures, etc.


- 1. Three or more people are required for the assembly.
 - 2. A ladder is recommended during assembly.
 - 3. Ensure you have all the required parts and organize them before assembling.
 - 4. An electric drill is recommended for the assembly.
 - 5. Do not use candles, matches or open flames of any kind inside or near a tent.
 - 6. Professional installation is highly recommended.


Item no. Nr. N° d'article Articolo No. Artículo No.	Reference Image Referenzbild Image de référence Immagine di riferimento Imagen de referencia	Qty. Menge Qté. Qtà Cant.	Item no. Nr. N° d'article Articolo No. Artículo No.	Reference Image Referenzbild Image de référence Immagine di riferimento Imagen de referencia	Qty. Menge Qté. Qtà Cant.
1	0 0	X20	G		X4
2	0 0	X10	a		X140
3	0 0	X10	b	φ3 Tent peg	X20
4	0 0	Х6	C	φ6 Tent peg	X8
5	0 000	X4	d		X8
6	0 0	X2	e		X1
7	•	X4	f		X2
A		Х6	g		X2
В		Х9	h	Bag	Х3
G		Х6	m		X28























Every part in the picture marked in blue must be installed with 6 bungee cord fasteners, while parts marked in red with 18 bungee cord fasteners. The poles marked in red can be temporarily secured first. The same fasteners are used to secure the cover cloth during step 9.


































a)56pcs f)2pcs g)2pcs

The fasteners marked in red are the same ones used in step 4. 4 bungee cord fasteners are needed for part 4 (marked in blue). 12 bungee cord fasteners are needed for part 5 (marked in yellow). 8 bungee cord fasteners are needed for part 6&7 (marked in green).










11






be sure to complete this installation step. If expansion screws or ground nails are not installed, strong winds may topple the gazebo.

Expansion screws are essential for stability on cement surfaces, and ground

nails are for grassy surfaces.

All are included in the accessories package.



Complete Installation

13

14