


Dear user Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully. 1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.			1: Num indicator A: Cap indicator M: Mode indicator Battery indicator 2.4G/OFF/BT mode switch MAC/WIN Type C port 2.4G receiver storage slot OS Support Slide the switch button at left side of keyboard for MAC/WIN OS Support OS list: Windows XP/ Vista/ Win 7/ Win 8/ Win 10/Win 11/Mac OS How to connect the keyboard with a computer Wired Connection 1. Slide the 2.4G/OFF/BT switch on left side of the keyboard to OFF. 2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer. 3. The computer will recognize and configure the keyboard automatically, The LED marked with M lights on Green. 4. Once the keyboard is powered up, charging begins. The LED marked with M lights on red. 2.4G Wireless Connection 1. Slide the 2.4G/OFF/BT switch on left side of keyboard to 2.4G. 2. press [FN]+[4] for about 3 seconds, the LED marked with M will flash in yellow, plug the USB receiver into any available USB port on your computer within 20 seconds. The	computer will recognize and configure the keyboard automatically, LED marked with M will light on yellow steady. Bluetooth Connection 1. Slide the 2.4G/OFF/BT switch on left side of keyboard to BT. 2. Press [FN]+[1](or [2]/[3] for other Bluetooth devices), the LED marked with M flashes in blue (or cyan/magenta for the others) 3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0Keyboard or BT5.0 KB" device. Select one of them to get connected with it automatically. Keyboard sleep mode and power save function In 2.4Ghz and Bluetooth connecting, to save power, there are two coditions that keyboard get into sleep mode, all LEDs and backlight turn OFF, please click any key to wake up the keyboard. 1. power save mode at the first 3 minutes out of working, all backlight turns OFF, keyboard is working, 2.4G connecting is activity. 2. Sleep mode at the 30 minutes out of working, backlight turns OFF, keyboard is OFF, 2.4G is not connecting. Backlight setting [FN]+[INS]: Change backlight mode. [FN]+[PGUP]: Change backlight color under available patterns. [FN] + [←]: Slow down the backlight rotating speed. [FN] + [→]: Add up the backlight rotating speed. [FN] + [↑]: Level Up the backlight brightness. [FN] + [↓]: Level down the backlight brightness. [FN] + [ESC]: Press and hold for 3 seconds to default setting.	Backlight recording function 1. Press FN+Backspace, ESC、A、S、D、W、↑、↓、←、→ keys light ON indication its ready for recording. 2. Press FN+Backspace again to get ready for recording. 3. Keep press the desired key to choose lighting color, The indicator A keep flash during the recording, press FN+Backspace to save and quit. Commands of key combinations in Windows OS FN+F1 = Screen brightness- FN+F2 = Screen brightness+ FN+F3 = Multiple task FN+F4 = Voice(Up to WIN10) FN+F5 = Computer desk FN+F6 = Search FN+F7 = Previous track FN+F8 = Play/pause FN+F9 = Next track FN+F10 = Mute FN+F11 = Volume- FN+F12 = Volume+ FN+P = Home FN+[= END FN+)] = SCRLK FN+;; = PRTSC FN+"" = PAUSE
1	2	3	4	5	6

Commands of key combinations in MAC OS F1 = Screen brightness- F2 = Screen brightness+ F3 = Multiple task F4 = Siri F5 = Computer desk F6 = Search F7 = Previous track F8 = Play/pause F9 = Next track F10 = Mute F11 = Volume- F12 = Volume+ FN+P = Home FN+[= END FN+)] = SCRLK FN+;; = PRTSC FN+"" = PAUSE

Knob function

A. Knob default function as volume control(Check the following photo for volume control function),Short press knob to mute what playing, press it again to play.
Long press for 3 seconds.

B. Long press knob for 3 seconds, keyboard LEDs flash twice,

封底

封面

型号	K686WBG-RGB-MAX/7199		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷				
名称	说明书						
日期	2024-6-18						
页码	1 OF 1		文件编号				
绘图	雷国建	审核	香敏琪	核准		版本	A.1

