




9


Illustrated Parts List

Model 390 Series



Ref.	Part No.	Part Description
1	712-0442	Acorn Lock Nut 1/4-20
2	736-3020	Flat Washer.271" I.D. x.630" O.D.
3	720-0270A	Reverse Handle Grip
4	731-1600	Handle Cover w/o throttle
5	710-0779A	Truss Mach. Scr. #10 x 1/2" Lg.
6	720-0274	Handle Grip
7	712-3006	Hex Nut 1/4-20 Gr.2
8	726-0135	Cap Speed Nut
9	686-0083	Clutch Handle Assembly
10	720-0269	Clutch Grip
11	710-0641	Hex Bolt 1/4-20 x 2.25" Lg. Gr.5
12	731-1645A	Clutch Handle Holder
13	736-0140	Flat Washer.385" I.D. x.62" O.D.
14	686-0014A	Reverse Handle Ass'y
15	736-0264	Flat Washer.344" I.D. x.62" O.D.
16	649-04040	Handle Assembly Comp.
19	749-1401	Handle Brace
20	736-0921	Lock Washer 1/2
21	710-3194	Hex Bolt 1/2-20 Gr. 5
22	786-0005	Depth Bar
23	714-0149B	Cotter Pin
24	712-04063	Hex Flange L-Nut 5/16-18 Thd. Gr.5
25	786-0003	Tail Piece Bracket (L.H.)
26	786-0004	Tail Piece Bracket (R.H.)
27	711-0415	Clevis Pin

Ref.	Part No.	Part Description
28	710-0805	Hex Bolt 5/16-18 x 1.5" Lg.
29	710-0189	Hex Bolt 5/16-18 x 3" Lg.
30	736-0242	Wash. Bell.340" I.D. x.872" O.D.
31	711-1036A	Spec. Hex Nut
32	736-0119	L-Wash. 5/16" I.D.
33	710-3008	Hex Bolt 5/16-18 Gr. 5
34	786-0129	Cable Guide Bracket
35	710-0604A	Hex Washer Screw 5/16-18 x.62" Lg.
36	710-0602	Hex Wash. Hd. TT-Tap Scr.
37	738-0934	Shdl. Bolt 5/16-18
38	786-0138A	Frame (R.H.)
39	786-0139A	Frame (L.H.)
40	736-0171	Lock Washer 7/16
41	712-0240	Jam Nut 7/16-20 Gr. 2
42	710-0176	Hex Bolt 5/16-18 x 2.75" Lg.
43	712-0429	Hex Nylon Nut 5/16-18 Thd.
46	686-0081A	Wheel Hanger Bracket Assembly
47	734-1781	Wheel Ass'y 8" x 1.75"(Plastic)
	734-1566	Wheel Ass'y 8" x 1.75" (Steel)
48	738-0929	Shoulder Screw.496 I.D. x 1.445 O.D.
49	750-0890	Spacer
50	710-1236	Carr. Bolt 5/16-18 x 1
51	736-0242	Bell. Wash.34" I.D.
52	720-0195	Hand Knob
53	750-0470	Spacer



9

Illustrated Parts List

Model 390 Series



Ref.	Part No.	Part Description
1	712-0392	Hex L-Stop nut 1/4-28
2	736-3020	Flat Wash.266" I.D. x.625" O.D.
3	710-0599	Hex Washer TT-Tap Scr. 1/4-20 x.5"
4	711-0920	Belt Cover Bolt
5	712-04063	Hex Flange Top L-Nut 5/16-18
6	710-0723	Hex Hd. Scr. 3/8-16 x 1.25" Lg.
7	756-0313	Flat Idler Pulley 2.12" O.D.
8	786-0149	Idler Belt Keeper
9	786-0144	Idler Bracket
10	712-0266	Hex Cent. Jam Nut 3/8-16 Thd.
11	786-0057	Belt Cover
13	786-0043A	Tine Shield
14	710-3008	Hex Hd. Cap Scr. 5/16-18 x.75" Lg
16	686-0091	Chain Case Assembly Complete
17	686-0106	Outer Disc Plate Assembly
18	714-0149B	Internal Cotter Pin
19	711-0415	Clevis Pin
20	642-0023	Outer Tine Assembly L.H.
	642-0024	Outer Tine Assembly R.H.
21	642-0003	Inner Tine Assembly L.H.
	642-0002	Inner Tine Assembly R.H.
22	746-0918	Forward Clutch Cable
23	746-0953	Reverse Clutch Cable
24	756-0585	FI-Pulley 6" Dia.
25	750-0892	Spacer.64" Dia. x 2.4" Lg.

Ref.	Part No.	Part Description
26	748-0350	Pulley Mounting Adapter
27	736-0112	Bell-Wash.525" I.D. x 1.5" O.D.
28	712-3029	Hex Jam Nut 1/2-20 Thd.
29	732-0697	Return Spring
30	786-0040B	Reverse Bracket
31	736-0119	Lock Washer 5/16
32	710-0237	Hex Bolt 5/16-24 x.625"
33	756-0971	Engine Inner Half Pulley
34	756-0600	Reverse Engine Pulley
35	736-0452	Bell Washer.396" I.D. x 1/14" O.D.
36	710-1093	Hex Bolt 3/8-24 x 1.00"
38	686-0013	Reverse Arm Assembly
42	786-0041	Reverse Belt Keeper
43	710-0502A	Hex L-Wash. TT-Tap 3/8-16 x 1.25"
44	786-0145A	Engine Plate
45	786-0053	Tine Shield Bracket
46	736-0171	L-Wash. 7/16" I.D.
47	712-0240	Hex Nut 7/16-20 Thd.
48	754-0428	V-Belt (Forward) 1/2 x 41.9"
49	754-0429	V-Belt (Reverse) 3/8 x 45.68"
50	738-0102	Shld. Screw.498 x 1.445
51	738-0930	Shld. Screw.560 x.165
52	710-0805	Screw 5/16-18 x 1.50
53	712-3010	Hex Nut 5/16-18
54	736-0242	Bell Washer