







# UNIT SPECIFICATIONS AND FEATURES

## Product overview




## Accessories

Pump drain hose (only for units with the drain pump feature)	
Pump inlet hose (only for units with the drain pump feature)	
Normal drain hose	
Casters	 x 4

# SET UP INSTRUCTIONS

## Step 1:

Separate dehumidifier & bucket from the nested shipping/storage position. Remove all packaging materials from the unit.



Nested Shipping &  
Storage Position

Fig. 3a




Fig. 3b

## Step 2:

Rotate dehumidifier 90° and align the arrows on the two labels (one on the bucket and one on the dehumidifier) and carefully sit the dehumidifier down onto the bucket. The water level window in the bucket and the user interface buttons on the dehumidifier should be on the same side when properly stacked. Check to ensure the arrows on the unit and bucket are aligned as in Fig. 4c for proper operation.




Fig. 4a

Rotate dehumidifier 90°

User Interface  
Buttons and  
Water Level  
Window  
Aligned on the  
Same Side




Fig. 4b



Fig. 4c

## Step 3:

Plug the unit in and press the power button and the unit is ready to run in normal (bucket) mode.