



Quick Start Guide

720 Hi-Res
Webcam


I. Important - Warnings and Safety Instructions

1. Do not place the product near heat sources such as fire, radiators, stoves, light candles and other apparatus that produces heat.
2. Use only those accessories supplied by FINGERS.
3. It is recommended to refer all servicing to qualified personnel. Servicing is required when the device has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

II. In the box

- 1 x FINGERS 720 Hi-Res Web Camera
- 1 x Quick Start Guide
- 1 x Brand Note

III. Product Illustration



1. 720p Manual Focus Lens
2. Microphone
3. Webcam Main Body
4. Universal Clip/Base
5. Tripod Provision

IV. Setting up your webcam

Easy setup for Online Video Calls, Conference, Webinars, education, tutorials and more!

1. Different placements of your Webcam



Fixed on Tripod
(Tripod not bundled)




Flat on Table



Clamp the camera on
the Computer screen

2. Connecting your FINGERS Webcam



3. Installing FINGERS Webcam

As the Webcam comes driverless, it will detect and install driver automatically on your PC/Laptop.

For Windows 8 and above, it is not required to install any third-party applications to access the Webcam. It can be accessed in default camera, messaging/video calling applications which is built-in (installed) in your PC.

V. Compatibility

- With OS: Microsoft Windows 7, 8, 10, Mac OSx 10.4.8 above, Android and Linux
- With Video Apps: Popular Instant Messaging and Video conferencing applications such as Windows Live Messenger, Skype, Yahoo Messenger, Facebook Messenger & Google Gmail for Voice and Video Chat, Zoom, WhatsApp and more.

VI. Specifications

Interface	USB 2.0
Lens	720P 3.6 mm
Effective Pixels	0.9 MegaPixels / 720p
Max. Resolution Support	HD 1280 x 720 @ 30 fps
Image Sensor	1 /4" CMOS Sensor
Microphone	Built-in USB Mic
Focus Type	Manual Focus
Cable Length	1.7 m
Power Consumption	Max. 1 W
Dimensions	55.5 x 95 x 53.6 mm (H x W x D)
Weight	95 g

Ver.: 1.0.0 | fingers.co.in

*Product may not be compatible with few third party apps & web browsers. Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners and protected under IPR. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in

Please Note:

- Requires a USB port which provides 5 V power.
- Recommended to not to use USB Extension Cable or USB Hub to connect this product; it may cause failure/damage of the webcam.
- The video size or resolution varies depending on video software and hardware in use.