

Bottle Warmer & Sterilizer

Model: W3
Randell
Founder of GROUNSY

Product Name	Bottle Warmer & Sterilizer
Warranty	12Months
Product Model	W3
US Version	120V~60Hz
Rated Power	250W
Recommended Humidity	50-80%
Recommended Temperature	15-30°C
Package	1pc
Recommended Environment	Indoor
Product Capacity	400ml

Task Manual: (Add 80ml/2.7oz purified water) Quickly warm a bottle of milk in 3-7 minutes and sterilize bottles before use. Screen shows timer countdown. Turn the bottle warmer off immediately after warming to the right temperature to avoid overheating. (Use 2oz/60ml purified milk, valuable nutrients and vitamins bottles.)

Milk Warming: (Add purified water to MAX line mark) Screen shows heating time in minutes. Server shows heating time in minutes. **Appliance will " beep " for 10 minutes when temp of milk is ok.** Appliance will " beep " for 10 minutes after warming to the right temperature to avoid overheating. Leave coffee in the warmer 15 minutes more if temperature is not warm enough. It will stop automatically after 30 minutes. After the function is finished, please use the "Fast & Sterilize" as return.

24H: (Add purified water to MAX line mark) Milk is warmed at a slower speed (about an hour) at set temperature and will stop after 24 hours. Defrost a bottle of milk to liquid state. Screen shows self-temperature in degree centigrade.

Freeze/Defrost: (Add purified water to MAX line mark) Heating water to desired set temperature in about an hour (frozen). Screen shows self-temperature in degree centigrade. Screen shows self-temperature in degree centigrade.

*Note: The top lid has 2.8litre window for tall bottles. Pay attention to prevent burns during use. Please don't touch until cooling down.

HEARTFELT THANK YOU


Thank you so much for trusting us from an early pregnancy and trust in our brand. GROUNSY is committed to allowing young parents of the new generation to experience the beauty and all-round emotional connection with our brand. GROUNSY is willing to be a companion on the path of parenting for expectant mothers, accompanying them through their journey together, accompanying novice mothers through busy childcare days, and helping them through their growth and happy days by day, making GROUNSY a tangible growth oriented mother and baby brand.

For any questions or issues, please email us: service@grownsy.com

Or SMS GROUNSY to 01(833)524-0498

We will go above and beyond to resolve any customer issue within 24 hours.

Randell
Founder of GROUNSY



Instructions:

Please check all parts of the bottle warmer before using. Put the bottle warmer on a horizontal plane. Make sure that the bottle warmer has been heated before adding water. Before connecting the power plug, please check the voltage for the bottle warmer.

Below figures are for "fast, milk/food warming, 24h" only for "Sterilize" please refer to below detail explanation.

EN

1. Press the power button. Power light is on. Then touch the "FAST & STERILIZE" function. The default heating time is 3mins. Press "+" to adjust time according to the Reference sheet followed. This bottle warmer has smart memory function. It will remember last time's setting to save your trouble to set time again next time. The bottle warmer will start working automatically in 3 seconds after you finished selecting function.

EN

1. Press the power button. Power light is on. Then touch the "FAST & STERILIZE" function. The default heating time is 3mins. Press "+" to adjust time according to the Reference sheet followed. This bottle warmer has smart memory function. It will remember last time's setting to save your trouble to set time again next time. The bottle warmer will start working automatically in 3 seconds after you finished selecting function.

Fast & Sterilize

USAGE 1: Fast Warming

1.Fill the chamber with 80 ml distilled water and cover the lid.(It is recommended to use distilled/purified water to prevent scale.)

2.Put the milk bottle into the bottle warmer.

3.Press the power button. Power light is on. Then touch the "FAST & STERILIZE" function. The default heating time is 3mins. Press "+" to adjust time according to the Reference sheet followed. This bottle warmer has smart memory function. It will remember last time's setting to save your trouble to set time again next time. The bottle warmer will start working automatically in 3 seconds after you finished selecting function.

Fast & Sterilize

4. The bottle warmer will count down automatically and the screen shows remaining heating time. Take bottle out in time when time is up to avoid over-heating.

5.Before feeding,shake the milk well and make sure the temp is suitable for feeding.

Note:

1.The speed of warming milk depends on the amount of the milk warmed and on its initial temperature, i.e., room temperature (20°C) or fridge temperature (4°C).

2. When you find the milk is not warm enough, you can place the bottle back into the appliance for a maximum of 0.5-1 minute of extra warming. This will create a slightly warmer result but without overheating.

3. If you know the bottle in the bottle warmer longer than the time indicated in the settings table, the milk may become overheated. Note: If you over-heat breast milk, valuable nutrients and vitamins may be lost.

4. Always check the temperature before you feed your baby. Gently shake the bottle or milk storage container and check the temperature of the milk by sprinkling a few drops on the inside of your wrist.

Caution: The water in the bottle warmer might be hot after finishing warming milk / baby food. Be careful that hot water can cause serious burns.

Reference Chart Only For Fast Warming Function

Milk Volume	60-70ml	70-80ml	80-90ml	90-100ml
Room Temp	4-5 min	5 min	6 min	7 min
Fridge	4 min	4 min	5 min	6 min
Freeze	6 min	7 min	8 min	10 min
24H	11-15 min	11-15 min	11-15 min	11-15 min
Defrost	3 min	3 min	3 min	3 min
Milk	3 min	3 min	3 min	3 min

Sterilize

USAGE 2 - STERILIZE

1.Fill the chamber with 80ml distilled water and cover the lid. (It is recommended to use distilled/purified water to prevent scale.)

2. Put the milk bottles/cups upside down into the basket first then put them into bottle warmer.

3.Press the power button then touch "Fast & Sterilize". Press "+" to set heating time to 15-20mins. The bottle warmer will start working automatically in 3 seconds after you finished selecting function.

Sterilize

4. The bottle warmer will count down automatically and the screen shows the remaining sterilizing time.

5. Bottle warmer will automatically off once the water dry out. Do not worry about the safety because GROUNSY bottle warmer will keep by steam. (Milk warming function will not be affected.) Slightly touch the power button can help you stop sterilization.

Milk Warming/Defrosting

1. Pour distilled water into the bottle warmer to scale line of the portable basket. (It is recommended to use distilled/purified water to prevent scale.) Take out the milk bottle from the refrigerator and place it into the bottle warmer.

2. Touch the power button and then choose "Milk Warming" function. Touch "+" to choose volume of the milk to be warmed. The bottle warmer will start working automatically in 3 seconds after you finish selecting function.

3. The screen shows warming time after warms. It will "beep" to remind you the bottle is ready. Check the temperature by sprinkling a few drops on the inside of your wrist. If the temperature is not warm enough, put the bottle back to warm extra 1-2 minutes.

Milk-Warming/Defrosting time reference

Milk Volume	60-70ml	70-80ml	80-90ml	90-100ml
Glass bottle	4-5 min	5-7 min	6-8 min	7-10 min
Plastic bottle	4-5 min	5-7 min	6-8 min	7-10 min
Flat bottle	4-5 min	5-7 min	6-8 min	7-10 min
24H	11-15 min	11-15 min	11-15 min	11-15 min
Defrost	3 min	3 min	3 min	3 min
Milk	3 min	3 min	3 min	3 min

Constant Warming Milk at 37°C/98.6°F

1. Pour distilled water into the bottle warmer to scale line of the portable basket. (It is recommended to use distilled/purified water to prevent scale.) Take out the milk bottle from the refrigerator and place it into the bottle warmer.

2. Touch the power button then choose "24H" function. The default temp is 37°C/98.6°F and you can also adjust the temperature you wish in degree centigrade after warmer works. Milk will be ready in about an hour and set temperature stays on.

Constant Warming Milk at 37°C/98.6°F

4. Before feeding, shake the milk well and make sure the temp is suitable for feeding.

5. The bottle warmer will precisely keep the milk, water at the target temperature for 24 hours in "24H" mode. To every baby with sensitive stomach, it is recommended to over-heat or too cold. (It is not recommended to heat breast milk for too long.)

Heating Food at 60°C/140°F

1. Pour distilled water into the bottle warmer to the scale line (the scale line is inside the bottle warmer).

2. Put the baby food in a heat-resistant container and then put them into the bottle warmer.

3. Touch the power button then choose the "Food Heating" function. Touch "+" to choose the temperature you want to set. The bottle warmer will start working automatically in 3 seconds after you finished selecting function.

4. The screen shows set temperature flashes in degree centigrade after warmer works. Food will be ready in about an hour (frozen meat puree takes 3 hours) and set temperature stays on.

Heating Food at 60°C/140°F

5. Before heating and feeding, please remember to stir the food well and make sure the food can be heated evenly.

Caution

Cleaning

1. Unplug the bottle warmer and make sure it cooling down before cleaning.

2. Do not immerse the working base for cleaning.

3. It is recommended to use distilled water to prevent scale. Acetic acid or other descalers can help you clean the scale efficiently.

Descaling

It is recommended to descale the bottle warmer every 4 weeks to ensure it continues to work efficiently.

1. Mix 10% citric acid cleaner with 200ml/7oz of cold water to descale the bottle warmer. Turn on the bottle warmer, select the STERILIZING FUNCTION then wait for 2-3 minutes after boiling, the descaling is completed.

2. Mix 50ml/1.7 oz of white vinegar with 100ml/3.5oz of cold water to descale the bottle warmer. Switch on the bottle warmer, select the MILK WARMING FUNCTION and wait for 10 minutes. Leave the solution in the bottle warmer until all scale has dissolved.

*Note:
1) Never dry out.
2) Do not use other types of descalers.

WARRANTY & CUSTOMER SERVICE

GROUNSY strives for user friendly products for newborn and household items. We aim not only to create a product, but also an item that is filled with care from us to our customers. If you have any questions or concerns, please contact us directly (service@grownsy.com) and we will help you out.

Or SMS GROUNSY to 01(833)524-0498

REGISTER YOUR FREE WARRANTY

At GROUNSY we only use the highest quality products standard - so please don't forget to register for your FREE one year warranty!

www.grownsy.com/warranty

GROUNSY

Manual de usuario del esterilizador y calentador de biberones

Lea este manual del usuario detenidamente antes de utilizar el esterilizador y calentador de biberones.

Descripción: Biberón calientador y esterilizador
Placa de garantía: Año 1 año
Modelo: W3
Potencia: 120V ~, 60W
Temperatura recomendable: 15-30°C
Función: calentamiento rápido
Empaque: una pieza
Usamos del producto: 400ml

GRACIAS

Gracias por comprar con nosotros y por confiar en nuestra marca, GROUNSY. El mejor asistente para padres.

GrounSY crea productos para bebés modernos y bien pensados para la ciencia de los hijos. Basado en principios de diseño inteligente, GROUNSY ofrece una amplia gama para todos los escenarios que involucran a padres e hijos. Estamos comprometidos a crear una marca única para la ciencia de los bebés y bebés.

Con el concepto fundamental de "hacer productos ideales que resuelvan una única necesidad", GROUNSY se centra en los problemas más difíciles durante la producción y brinda a nuestros usuarios las soluciones más prácticas. Los productos GROUNSY nacen un desafío cotidiano, una solución práctica y un uso inteligente.

Si tiene alguna pregunta o problema, envíenos un correo electrónico: service@grownsy.com

O envíenos un SMS GROUNSY al (833)524-0498

Haremos todo lo posible para resolver cualquier problema del cliente dentro de las 24 horas.

Randell
Fundador de GROUNSY

EN

1. Press the power button. Power light is on. Then touch the "FAST & STERILIZE" function. The default heating time is 3mins. Press "+" to adjust time according to the Reference sheet followed. This bottle warmer has smart memory function. It will remember last time's setting to save your trouble to set time again next time. The bottle warmer will start working automatically in 3 seconds after you finished selecting function.

Instrucciones de operación

Antes del uso, revise el nivel de agua. Pruebe el dispositivo con agua hervida para asegurarse de que funciona correctamente.

1. Coloque la botella de leche en el calentador de biberones. Ajuste el tiempo de calentamiento de acuerdo a la tabla de referencia.

2. Presione el botón de encendido. La luz indicadora se enciende. El calentador de biberones comenzará a funcionar automáticamente en 3 segundos después de seleccionar la función.

3. Cuando termine el calentamiento, la luz indicadora se apagará y el calentador de biberones mostrará el tiempo de calentamiento restante.

4. Cuando termine el calentamiento, retire la botella de leche y asegúrese de que la temperatura sea apropiada para alimentar.

EN

1. Press the power button. Power light is on. Then touch the "FAST & STERILIZE" function. The default heating time is 3mins. Press "+" to adjust time according to the Reference sheet followed. This bottle warmer has smart memory function. It will remember last time's setting to save your trouble to set time again next time. The bottle warmer will start working automatically in 3 seconds after you finished selecting function.

Esteriliza y calienta biberones rápidamente

4. Lo scaldabibero mostra automaticamente il controllo rimaente.

5. El calentador de biberones se apaga automáticamente cuando se agote el agua. No se preocupe por la seguridad, porque el calentador GROUNSY tiene la función de calentamiento Anticoque incorporada. Tocar ligeramente el botón de alimentación le ayudará a detener la esterilización.

Esteriliza y calienta biberones rápidamente

Nota:

1. La velocidad de calentar leche depende de la cantidad de la leche calentada y su temperatura inicial. Por ejemplo, la temperatura ambiente (20 °C) o la temperatura del frigorífico (4 °C).

2. Al descubrir que la leche no está lo suficientemente caliente, puede volver a poner la leche en el aparato para un máximo de 0.5-1 minuto de calentamiento adicional. Esto creará un resultado ligeramente más caliente pero no sobrecalentamiento.

3. Si pone la botella en el calentador de biberones durante el tiempo que se indica en la tabla de configuración, la leche puede sobrecalentarse. Si sobrecalienta, se pueden producir vómitos, molestias y vómitos.

Nota: Si calienta en exceso la leche materna, se pueden producir vómitos, molestias y vómitos.

4. Consume siempre la temperatura antes de alimentar a tu bebé. Agite ligeramente la botella o el envase de conservación de la leche y compruebe la temperatura de la leche golpeando unas gotas en el costado de su muñeca.

Precaución: El agua en el calentador de biberones podría estar caliente después de haber estado en el calentador de biberones de bebé. Tenga cuidado de que el agua caliente pueda provocar quemaduras graves.

Esterilizar

4. Lo scaldabibero mostra automaticamente il controllo rimaente.

5. El calentador de biberones se apaga automáticamente cuando se agote el agua. No se preocupe por la seguridad, porque el calentador GROUNSY tiene la función de calentamiento Anticoque incorporada. Tocar ligeramente el botón de alimentación le ayudará a detener la esterilización.

Calentamiento de leche

1. Agregar el agua destilada en el calentador de biberones a la línea de escala de la canasta portátil (la línea de escala queda dentro de la canasta). Coloque el biberón dentro del frigorífico y colóquelo en el calentador de biberones.

2. Ponga la botella de leche en un recipiente termoisulante y luego póngalo en el calentador de biberones.

3. Presione el botón de alimentación, luego toque la función "Fast & Sterilize". Presione "+" para configurar el tiempo de calentamiento de leche. El calentador de biberones comenzará a funcionar automáticamente en 3 segundos después de seleccionar la función.

3. La pantalla visualiza el tiempo de calentamiento después de que el calentador de biberones comienza a funcionar. Cuando el tiempo de calentamiento se haya completado, la pantalla mostrará la temperatura establecida en Celsius. La pantalla mostrará aproximadamente una hora (o horas para puré congelado) y la temperatura establecida en la pantalla sigue siendo la misma.

Calentamiento constante a 37°C/98.6°F

4. Antes de alimentar, agite bien la leche y asegúrese de que la temperatura sea apropiada para alimentar.

5. El calentador de biberones mostrará el tiempo de calentamiento restante.

6. Cuando termine el calentamiento, retire la botella de leche y asegúrese de que la temperatura sea apropiada para alimentar.

Calentamiento de los Alimentos a 60°C/140°F

1. Agregar el agua destilada en el calentador de biberones a la línea de escala de la canasta portátil (la línea de escala queda dentro de la canasta). Coloque el biberón dentro del frigorífico y colóquelo en el calentador de biberones.

2. Ponga los alimentos de biberón en un recipiente termoisulante y luego póngalo en el calentador de biberones.

3. Toque el botón de alimentación, luego toque la función "Food Heating" para calentar alimentos. La temperatura establecida en Celsius se mostrará en la pantalla. La pantalla mostrará aproximadamente una hora (o horas para puré congelado) y la temperatura establecida en la pantalla sigue siendo la misma.

Desincrustación

Es aconsejable desincrustar el calentador cada 4 semanas, para asegurarse de que sigue trabajando eficientemente.

1. Mezcle 10 g de limpiador de ácido cítrico con 200 mililitros (7 oz) de agua fría para descalcificar el calentador de biberones. Coloque el calentador de biberones, seleccione la FUNCIÓN ESTERILIZADORA, espere 2-3 minutos después de hervir, se completará la descalcificación.

2. Mezcla 50ml/1.7oz de vinagre blanco y 100ml/3.5oz de agua fría, para desincrustar el calentador. Inicia el dispositivo, escoger el modo de calentación de leche y lo deja trabajar durante 10 minutos. Después de la desincrustación el calentador hasta que la incrustación disuelva completamente.

*Nota:
1. Nunca se seque.
2. No usa otros tipos de desincrustante.

Puntos de advertencia:

1. Antes de limpiar, asegure de que el calentador de biberones esté apagado y se haya enfriado. 2. No limpie la base del calentador de biberones con agua caliente y espere que se enfríe. 3. Por favor intente usar el agua para evitar que haya incrustación en el calentador de biberones, y después de que salga la incrustación se limpia.

GARANTÍA Y SERVICIO AL CLIENTE

GROUNSY se esfuerza por ofrecer productos fáciles de usar para recién nacidos y artículos para el hogar. Nuestro objetivo no es solo crear un producto, sino también un producto que esté lleno de amor por parte de nuestros clientes. Si tiene alguna pregunta o problema, envíenos un correo electrónico: service@grownsy.com y si es necesario, llámenos al (833)524-0498.

O envíenos un SMS GROUNSY al (833)524-0498

REGÍSTRSE SU GARANTÍA GRATUITA

En GROUNSY solo usamos el mejor de los productos de la más alta calidad, pero no olvide registrarse para obtener su garantía GRATUITA de un año por escrito.

www.grownsy.com/warranty

GARANTÍA Y SERVICIO AL CLIENTE

GROUNSY se esfuerza por ofrecer productos fáciles de usar para recién nacidos y artículos para el hogar. Nuestro objetivo no es solo crear un producto, sino también un producto que esté lleno de amor por parte de nuestros clientes. Si tiene alguna pregunta o problema, envíenos un correo electrónico: service@grownsy.com y si es necesario, llámenos al (833)524-0498.

O envíenos un SMS GROUNSY al (833)524-0498

REGÍSTRSE SU GARANTÍA GRATUITA

En GROUNSY solo usamos el mejor de los productos de la más alta calidad, pero no olvide registrarse para obtener su garantía GRATUITA de un año por escrito.

www.grownsy.com/warranty