


GETTING STARTED




POWERING THE SPEAKERS



FOR CREATIVE PEBBLE


Simply connect the Creative Pebble to your PC or Mac via the (1) USB-A cable for power and the (2) 3.5 mm AUX-in cable for audio.



FOR CREATIVE PEBBLE V2

Connect the Creative Pebble V2 to your PC or Mac via the (1) USB-C cable for power and the (2) 3.5 mm AUX-in cable for audio.

If your PC or Mac comes with a USB-A port, please use the provided (3) USB-C to USB-A converter.




FOR CREATIVE PEBBLE PLUS

To start, connect the (1) RCA cable to subwoofer for better bass performance.

Then, connect the Creative Pebble Plus to your PC or Mac via the (2) USB-A cable for power and the (3) 3.5 mm AUX-in cable for audio.

Alternatively, you can also power the Creative Pebble series speaker with Creative 30W PD Adapter.



FOR ALL PEBBLE SERIES SPEAKERS

SWITCHING ON / VOLUME

Off / Vol -

Vol + / Max



To switch on the Creative Pebble V3, simply turn the volume knob clockwise. The LED indicator will be in blue color when the speaker is switched on.

If the Creative Pebble V3's volume remains low even when the speakers are at maximum volume:

1. Ensure that your device's (e.g. laptop, desktop or mobile phone) volume is turned up. The Creative Pebble V3's volume is independent of your device—both will need to be turned up to an acceptable level.
2. If the audio level remains low, the Creative Pebble V3 is most likely not receiving sufficient power from your device. This is a common occurrence found in older computers and laptops. We recommend you to connect the speakers directly to a wall adapter and use an AUX-in cable for the audio output.

CONNECTIVITY

Connecting to PC

Your PC will automatically detect the Creative Pebble V3 when you plug in the USB cable.

If you do not hear any audio playing from the speaker, check the output device list from the 'Sound' setting and set Creative Pebble V3 as the default output speaker.



Connecting to Mac

For Mac users, you will need to adjust your audio settings.

Choose **Apple Menu > System Preferences**, click 'Sound', then click 'Output' to select 'Pebble V3'.



Connecting to MP3 / Other Audio Devices*

You can also connect the speaker to your analog devices like Echo Dot, MP3 Players, or mobile phones via 3.5 mm AUX-in cable.

*Note that the speaker has to be powered via USB while connected via AUX-in.



FOR CREATIVE PEBBLE V2 AND PEBBLE PLUS

HIGH / LOW GAIN SWITCH

A < GAIN > H



The speakers are set to High Gain Mode out of the box.

When plugged in to a 10W USB-C or USB-A port, the built-in gain switch located at the bottom of the right speaker satellite will activate the High Gain Mode that delivers acoustic power of up to 8W RMS and peak power of up to 16W, giving you louder, powerful audio.

MORE QUESTIONS?

If you require more assistance, please do not hesitate to contact us directly on Amazon. Alternatively, you can also find our support materials and help resources online easily.