

材质: 128G铜版纸单色印刷, 风琴折
尺寸: 98*140mm

1

2

3

4

封底

Table of Contents

1. Package Contents02

2. Button Configuration02

3. Connectivity03

4. Basic Operation04-05

5. Pairing Process06

6. TWS Pairing Process06

7. Modes and Functions07

8. Product Specification08

9. Care and Maintenance08

Thank you for purchasing your new GEARi Boombox Bluetooth Speaker. This user manual will help provide you with all the information needed to get started. Please read this manual carefully before using the product and reference it for later use.

Enjoy your new product.

Live it. Experience it. GEARi.

1. Package Contents

Bluetooth Speaker x1

USB-C Charge Cable x1

3.5mm Cable x1

Shoulder Belt x1

User Manual x1

1. Power Button

2. RGB Modes

3. Play/Pause Answer/Refuse Calls

4. Volume+ /Next Track

5. TWS Status LED

6. Power Status LED

7. Input Switch / Activate Voice Assistant*

8. Bluetooth / TWS Button

9. Volume- / Previous Track

10. Bluetooth Status LED

-02-

*When paired to a mobile device.

3. Connectivity

1. USB-C Charging Port

2. 3.5mm Aux-In Port

3. 6.35mm MIC IN Port

4. TF/MicroSD Card Slot

5. USB-A Port

-03-

4. Basic Operation

Play/Pause Button

x1▶/⏸

Play/Pause: Press Once

x1📞

Answer/Hang up a Call: Press Once

x2s⏮

Reject a Call: Press and Hold 2s

Volume-Button

x1🔊

Turn Down Volume: Press Once

x2s⏮

Previous Track: Press and Hold 2s

Volume+Button

x1🔊

Turn Up Volume: Press Once

x2s⏭

Next Track: Press and Hold 2s

Pairing Button

x1🔗

Enter Bluetooth Pairing Mode: Press Once

x2s🔗

Enter TWS Pairing Mode: Press and Hold 2s

x2s🔗

Exit TWS Pairing Mode: Press and Hold 2s

x8s🔗

Reset Connection: Press and Hold 8s

-05-

5. Pairing Process

1. Turn on the Bluetooth Speaker.

2. If the speaker reconnects to its last paired device automatically, press "p2" to enter Bluetooth pairing mode.

3. Activate Bluetooth on your device and search for "GEARi Boombox", tap to connect.

6. TWS Pairing Process

1. Ensure both speakers are not connected to any devices before pairing.

2. Power on both speakers. Press and hold the "p2" on either speaker to enter TWS mode. This speaker becomes the main unit (left channel), so place it on your left.

3. Once TWS pairing is done, the main speaker's white light will be solid and the secondary speaker's white light will flash slowly. Blue light of main speaker is flashing while the blue LED of the other is solid.

4. The secondary speaker is the right channel, so place it on your right.

5. Search for "GEARi Boombox" on your device's Bluetooth settings and connect to enjoy the stereo sound.

-06-

7. Modes and Functions

Power Bank Function

When the speaker is powered on, connecting a cable to its USB-A port enables emergency charging for your smartphone or other devices.

Aux/MicroSD Card/USB Drive Modes

In addition to Bluetooth mode, playback is also available via Aux, MicroSD card, and USB drive modes.

Automatic Power Off

The speaker will automatically turn off after 30 minutes of inactivity. (No connections with Bluetooth, MicroSD card, AUX cable, or USB drive).

Wired Karaoke Function

GEARi Boombox can be used as a karaoke speaker since it has a 6.35mm mic input.

-07-

8. Product Specification

Model

GI-SPK-BT-BOOM-BK

Color

Black

Bluetooth Version

5.3

Frequency Range

65Hz - 20KHz

Input Power

5W/2A via USB-C Port

Battery Capacity

74V/4000mAh

Playback Time

Up to 12 Hours @ 65dB SPL

Charging Time

5 Hours

9. Care and Maintenance

Do not use any form of detergents or cleaning materials to clean the product, as any type of chemical may make this device unusable.

Do not disassemble this product. It contains no user serviceable parts.

Do not drop the product or jump on it. Treat it with care for the best performance.

Keep the product in a dry location. Dust, dirt, and moisture from humidity can accumulate on the body of the product.

Do not dispose this product in fire, or batteries may leak or explode.

-08-

10. RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

GEARi LIMITED WARRANTY

Warranty Coverage

We warrant limited our products with confidence, offering warranties designed to give you peace of mind and a worry-free experience. Our commitment covers most GEARi products with specific warranty periods listed on product type such as cables, cases, wall chargers, and more. Other warranties are protected from defects in materials and workmanship.

Speakers (Bluetooth Products) 24 Months

30-Day Money-Back Guarantee

You may return unchanged products within 30 days for all returns. Products must include all accessories and original packaging. Shipping costs for non-quality-related returns are the responsibility of the buyer.

Replacement Warranty

If a defect occurs within the warranty period, GEARi will repair, replace, or issue a credit for the product. Repaired or replacement products are covered for 90 days or the remainder of the original warranty, whichever is longer.

Read Assistance

For more information or to file a warranty claim, please visit GEARi's Warranty Support (<https://www.gearid.com/contact/warranty-information>)

United States Only

www.gearid.com

support@gearid.com

1-800-225-8244

www.gearid.com

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, which means that it may cause some interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/television technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: This product can expose you to chemicals known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.

GEARi

Boombox Bluetooth Speaker with RGB Lighting

GI-SPK-BT-BOOM-BK

User Manual

-09-

5

6

7

8

封面

Poppin Bold/Poppin 字体