




| Original                                                                              | Replacement     | Original                                                                              | Replacement |
|---------------------------------------------------------------------------------------|-----------------|---------------------------------------------------------------------------------------|-------------|
|      | Power           |      | Power       |
|      | A               |      | Red         |
|      | B               |      | Green       |
|      | C               |      | Yellow      |
|      | D               |      | Blue        |
|      | E               |      | 3D          |
|      | F               |      | Shift + 6   |
|      | G               |      | Shift + 7   |
|      | Reset / Upgrade |      | Exit        |
|     | Recall / Info   |     | Info        |
|    | Guide           |    | Guide       |
|    | Home / Menu     |    | Menu        |
|    | Back / PP       |    | Back        |
|    | Options         |    | Options     |
|    | Smart           |    | Smart       |
|    | Up              |    | Up          |
|    | Left            |    | Left        |
|    | OK              |    | Ok          |
|    | Right           |    | Right       |
|    | Down            |    | Down        |
|    | Teletext        |    | Text        |
|    | CC              |    | Subt        |
|    | TV Vol +        |    | Vol +       |
|    | TV Vol -        |    | Vol -       |
|    | Mute            |    | Mute        |
|    | P+              |    | Ch +        |
|   | P-              |   | Ch -        |
|  | 1               |  | 1           |
|  | 2               |  | 2           |
|  | 3               |  | 3           |
|  | 4               |  | 4           |
|  | 5               |  | 5           |
|  | 6               |  | 6           |
|  | 7               |  | 7           |







| Original                                                                              | Replacement     | Original                                                                              | Replacement |
|---------------------------------------------------------------------------------------|-----------------|---------------------------------------------------------------------------------------|-------------|
|      | Power           |      | Power       |
|      | A               |      | Red         |
|      | B               |      | Green       |
|      | C               |      | Yellow      |
|      | D               |      | Blue        |
|      | E               |      | 3D          |
|      | F               |      | Shift + 6   |
|      | G               |      | Shift + 7   |
|      | Reset / Upgrade |      | Exit        |
|     | Recall / Info   |     | Info        |
|    | Guide           |    | Guide       |
|    | Home / Menu     |    | Menu        |
|    | Back / PP       |    | Back        |
|    | Options         |    | Options     |
|    | Alarm / Clock   |    | Media       |
|    | Smart           |    | Smart       |
|    | Up              |    | Up          |
|    | Left            |    | Left        |
|    | OK              |    | Ok          |
|    | Right           |    | Right       |
|    | Down            |    | Down        |
|    | Teletext        |    | Text        |
|    | CC              |    | Subt        |
|    | TV Vol +        |    | Vol +       |
|    | TV Vol -        |    | Vol -       |
|    | Mute            |    | Mute        |
|   | P+              |   | Ch +        |
|  | P-              |  | Ch -        |
|  | 1               |  | 1           |
|  | 2               |  | 2           |
|  | 3               |  | 3           |
|  | 4               |  | 4           |
|  | 5               |  | 5           |
|  | 6               |  | 6           |







| Original                                                                            | Replacement   |
|-------------------------------------------------------------------------------------|---------------|
|    | Power         |
|    | Recall / Info |
|    | Guide         |
|    | Home / Menu   |
|    | Back / PP     |
|    | Options       |
|    | Alarm / Clock |
|    | Smart         |
|    | Up            |
|   | Left          |
|  | Ok            |
|  | Right         |
|  | Down          |
|  | Teletext      |
|  | CC            |
|  | TV Vol +      |
|  | TV Vol -      |

| Original                                                                              | Replacement |
|---------------------------------------------------------------------------------------|-------------|
|    | Mute        |
|    | P+          |
|    | P-          |
|    | 1           |
|    | 2           |
|    | 3           |
|    | 4           |
|    | 5           |
|    | 6           |
|   | 7           |
|  | 8           |
|  | 9           |
|  | 0           |
|  | AV          |
|  | Sleep       |





| Original                                                                            | Replacement   |
|-------------------------------------------------------------------------------------|---------------|
|    | Power         |
|    | Recall / Info |
|    | Guide         |
|    | Home / Menu   |
|    | Back / PP     |
|    | Options       |
|    | Alarm / Clock |
|    | Smart         |
|    | Up            |
|   | Left          |
|  | Ok            |
|  | Right         |
|  | Down          |
|  | Teletext      |
|  | CC            |
|  | TV Vol +      |
|  | TV Vol -      |

| Original                                                                              | Replacement |
|---------------------------------------------------------------------------------------|-------------|
|    | Mute        |
|    | P+          |
|    | P-          |
|    | 1           |
|    | 2           |
|    | 3           |
|    | 4           |
|    | 5           |
|    | 6           |
|   | 7           |
|  | 8           |
|  | 9           |
|  | 0           |
|  | AV          |
|  | Sleep       |

