


AL87 Hotkeys




Fn+	F1	=	File Explorer
	F2		E-mail
	F3		Windows Search
	F4		Browser Homepage
	F5		Media

Fn+	F6	=	Pause / Playback
	F7		Previous Song
	F8		Next Song
	C		Calculator
	M		Mute

Fn+	<	=	Decrease Volume
	>		Increase Volume
	W		Swap W A S D with ↑ ↓ ← →

AL87 System Commands (Windows)



Lock Windows Key

Press Fn and left Win key


Restore Factory Settings

Hold down left Win
and right Win key for 3s

Windows (default) ⇌ Mac OSX

Hold down Fn and press O key

AL87 System Commands (Mac)



F1 Decrease display brightness

F2 Increases display brightness

F3 Open mission control

F4 Activate Siri

F7 Skip back (Audio)

F8 Pause/Play (Audio)

F9 Skip forward (Audio)

F10 Mute

F11 Volume down

F12 Volume up

Left Win Option

Left Alt Command


Right Win Option

Right Alt Command

Fn + (F1 ~ F12)

F1 ~ F12

AL87 Backlight Settings



LED Indicator

1.Caps

2.Mac

3.Lock Win

Fn+	/	=	Switch between 18 different lighting effects based on QMK standard.
	L		Light On / Off
	Enter		The light effect will change in the following order in all RGB lighting modes: RGB, Red, Green, Blue, Orange, Purple, Yellow, and White.

Fn+	↑	=	Bright
	↓		Dim
	←		Light Saturation -
	→		Light Saturation +
	-		Slower Animation
	+		Faster Animation