

Quick Start Guide



See owner's manual for complete assembly and operating instructions and important safety information before using this product.

STEP 1



Set Steam Selector to Off

Ensure that the iron is detached from the Base Unit. Then, flip the switch to off.

STEP 2



Fill Water Tank

Lift the Water Tank Cap and slowly fill the water tank with water without filling past the max fill line. Close the Water Tank Cap.

STEP 3



Set Temperature

Attach the iron to the Base Unit, and plug the Base Unit into a power outlet. Then, set Temperature Control Dial to desired temperature.

STEP 4



Iron Cordlessly

To detach the iron from the base, unlock the Base Lock Switch. To use the iron cordlessly, place the iron on the base for about 8 seconds (until the Temperature Indicator Light darkens).*

STEP 5



Press Steam Blast Trigger

Set the Steam Selector to the desired setting. Use the Steam Blast Trigger to generate a powerful burst of steam.

BEFORE FIRST USE:

- Use the **PowerXL Cordless Iron & Steamer Deluxe** on a discardable cloth for a few minutes. This will ensure that any residue left over from the manufacturing process is burned off the Soleplate and will not transfer to your clothes. Any odor or smoke during this process is normal and should disappear quickly.
- Flush the system by filling the water tank, setting the iron on the highest temperature setting, and pressing the Steam Blast Trigger to release steam.

* You can also iron with the cord by attaching the iron to the base and locking the Base Lock Switch.

Iron Will Be Hot; Be Careful When Handling