


The default system of this product is Windows.



Quick Start Guide

1 Connect 2.4 GHz Receiver



Connect the 2.4 GHz receiver to the device USB port.




Switch toggle to 2.4GHz mode



G = 2.4GHz




Note: For the best wireless experience, we recommend using the extension adapter for receiver and putting the 2.4 GHz receiver somewhere on your desk close to your keyboard for a low rate of latency and fewer signal interferences.




2 Connect Bluetooth



Switch toggle to Bluetooth




Press Fn + 1 (for 4 seconds) and pair with device named Keychron P1 Pro



Fn + 1

3 Connect Cable



4 The Lemokey Launcher App

Please visit launcher.lemokey.com to access the keyboard online launcher app. This app enables users to remap keys, adjust key actuation points, assign multiple commands to a single key, enter game controller mode, and more.

If it cannot recognize your keyboard, please reach our support to get instruction.




*The online launcher App can only run on the latest version of Chrome, Edge, and Opera browsers yet.

*The online launcher App only works when the keyboard is connected by wire to the computer.

5 Switch to Mac

Please find the Mac keycaps in the box, and follow the instructions below to find and replace the following keycaps.




Use the online launcher app to remap the Windows keys to Mac keys.




7 Adjust The Backlight Brightness

Press Fn + W to increase the backlight brightness




Press Fn + S to decrease the backlight brightness




6 The Backlight

Press Fn + Q to change the lighting effect




Press Fn + Tab to turn the backlight on/off




8 Adjust The Backlight Speed


Press Fn + T to increase the light effect speed



Press Fn + G to decrease the light effect speed



9 Factory Reset



Troubleshooting? Don't know what's going on with the keyboard?

1. Download the right firmware and QMK Toolbox from our website.
2. Unplug the power cable and switch the keyboard to Cable mode.
3. Remove the space bar keycap to find the reset button on the PCB.
4. Hold the reset key first, then plug the power cable into the keyboard. Release the reset key after 2 seconds, and the keyboard will now enter DFU mode.

5. Flash the firmware with the QMK Toolbox.
6. Factory reset the keyboard by pressing Fn + J + Z (for 4 seconds).

* Step by step guide can be found on our website.

10 Warranty

The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.



Not Happy

support@lemokey.com