

INSTRUCTION MANUAL

1-Power Flow Pro+

10000mAh Magnetic Wireless Battery Pack



Wireless charging 15W (max.)

Qualcomm Quick Charge 3.0

Power Button	LED Display
Tap button once	LED displays the current battery level
Press and hold button for 3 seconds	Device and LED display powers off
Double tap button	Device enters "Low current charging mode", indicated by the LED flashing a flowing pattern that resembles "C". Double tap button again to exit mode.

Status	LED Display
Recharging this device via USB-C port	Last digit on the LED-Display flashes as the Q.Mag Power 13 charges. If fast charging is active, A " "icon will appear.
Multi-channel simultaneous output status	LED display the current battery level

Wireless charging status	The LED displays "  " the current battery level, the "  "will also be On.
Single output fast charging status	The LED displays the current battery level, the "  " icon will also be on.

SPECIFICATION

MODEL: IP127

Capacity : 10,000mAh (37Wh)

Rated Capacity : 5600mAh

USB-C Input : 5V3A, 9V2.22A, 12V1.67A

USB-C Output : 5V3A, 9V2.22A, 12V1.67A

Wireless Output : 15W

Multi-way Output : 5V3A

Material : PC + ABS

Size : 68.5 x 22 x 108mm

Weight : 239g±10g

CONTAINS:

1. 10000mAh Magnetic Wireless Battery Pack
2. USB-C to USB-C cable (1m)
3. Instruction manual and warranty card

WARNING

1. Do not dismantle or modify the product;
2. Do not store the product in wet conditions;
3. Do not keep or use the product near heat sources;
4. Do not let water or any other liquid flows into the inside part of the product's interface. This would cause damages to the product;
5. Avoid direct sunlight. Keep away from heat source;
6. Avoid high processor load in long running loops or while charging;
7. Ensure good ventilation while using;
8. In case of overheating, stop using the product.

DISPOSAL OF ELECTRONIC PRODUCTS

1. Do not place the product as household waste;
2. Please dispose of discarded electronic products properly according to local regulations.
3. MOMAX encourages you to participate in electronics recycling program.

WARRANTY CONDITIONS

1. For any defect, in the judgment of our technician, caused under normal use, we are responsible for repairing free of charges 12 months commencing from the date of purchase at the discretion of our company;
2. A valid warranty card and original purchase invoice must be presented upon request of warranty service;
3. This warranty card shall not apply to the product if:
 - (a) it has explicitly modified or repaired in any way by persons other than technicians of this company, or;
 - (b) it has been damaged through misuse, malicious acts, negligence, inflow of any liquid, or;
 - (c) losses or damages are caused by force majeure or natural disasters.
4. No alteration to this warranty card will be allowed;
5. The warranty terms and conditions are subject to change without prior notice;
6. Please retain your proof of purchase for warranty service;
7. Please consult the dealer about the product compatibility with your cell phone/ PDA before purchase. Product specifications are subject to change without prior notice;
8. Please visit www.momax.net for latest product information.