





Kitchen-bell Installation

⚠ CAUTION

- Before installation, be sure to turn off the power switch.
- Use gloves to protect your hand from being cut by the angle and the chassis.

UNPACKING







1. After Remove the two screws and separate the Interface-Board, Remove the screw and separate the CASE-UPPER from the CASE-LOWER.
2. Take the enclosed Melody PCB and fix the screws (2EA) as shown.
3. Fix the Melody PCB cable as shown.
Then Insert the connector to the Main PCB and reassemble the CASE-UPPER, CASE-LOWER.

키친벨 설치방법

⚠ 주의하세요!

- 멜로디보드를 설치 하기전에, 반드시 전원을 꺼주시기 바랍니다.
- 날카로운 부분에 손을 베이거나 다칠 수 있으니, 장갑을 착용한 후 설치를 하여 주시기 바랍니다.

포장물



1. 인터페이스 보드에 있는 조립스크류 2개를 풀고 인터페이스 보드를 분리한 후, 케이스 로워 바닥면에 있는 스크류를 풀고 케이스 어퍼와 케이스 로워를 분리합니다.
2. 동봉된 멜로디 보드를 그림과 같이 스크류 2개를 이용하여 고정합니다.
3. 멜로디 보드의 커넥터를 메인보드에 삽입한 뒤, 케이블을 그림과 같이 정리합니다. 케이스 어퍼와 케이스 로워를 해체했던 방법 반대로 재조립을 합니다.