

Quick Using Guide

1. Before turning on the camera, please insert a **branded U3 high-speed** Micro SD Card.
2. Plug into the power **using the car charger** we provided and please make sure to **keep** the camera plugged into the power **all the time**.
3. After plugging, the camera will turn on to record automatically, however, we **suggest you format** the Micro SD Card on the camera before recording for the first time.

EMAIL ADDRESS:



lamttotech@yoomail.com



Facebook



More Operation Questions
Please Scan QR Code to Watch
More Operation Videos

FQA

1. The Camera Displays "Memory Error".

- A. Please make sure you used the branded U3 high-speed Micro SD card.
- B. Please make sure to format the Micro SD card before recording.
- C. Please format the Micro SD card to FAT32/exFAT on the computer.

2. The Camera Turns on/off by itself.

- A. Please refer to the steps as the solution "Memory Error" first.
- B. Please make sure the power supply is normal.
- C. Please make sure Both functions "Motion Detection" and "Auto Power Off" are not enabled at the same time.

3. How to access the setup interface?

Please stop the recording first, then access the Setup interface, otherwise, cannot access it.

4. Why the camera cannot start recording after powered on?

- A. Please reset the camera manually.
- B. Please re-format the Micro SD card on the camera.

5. WIFI Connection Problem

- A. Please make sure the WLAN and Album permission on the phone is turned on.
- B. Please make sure to turn on WiFi on the camera.
- C. Please keep the camera close to the phone.